



FL SWITCH 2000

User manual

Order No. —

User manual

FL SWITCH 2000

2017-05-24

Designation: UM EN FL SWITCH 2000

Revision: 01

Order No.: —

This user manual is valid for:

Designation	Order No.	Designation	Order No.
FL SWITCH 2005	2702323	FL SWITCH 2206-2FX SM	2702331
FL SWITCH 2008	2702324	FL SWITCH 2206-2FX ST	2702332
FL SWITCH 2105	2702665	FL SWITCH 2206-2FX SM ST	2702333
FL SWITCH 2108	2702666	FL SWITCH 2204-2TC-2SFX	2702334
FL SWITCH 2205	2702326	FL SWITCH 2206-2SFX	2702969
FL SWITCH 2208	2702327	FL SWITCH 2308	2702652
FL SWITCH 2207-FX	2702328	FL SWITCH 2304-2GC-2SFP	2702653
FL SWITCH 2207-FX SM	2702329	FL SWITCH 2306-2SFP	2702970
FL SWITCH 2206-2FX	2702330		

Please observe the following notes

User group of this manual

The use of products described in this manual is oriented exclusively to:

- Qualified electricians or persons instructed by them, who are familiar with applicable standards and other regulations regarding electrical engineering and, in particular, the relevant safety concepts.
- Qualified application programmers and software engineers, who are familiar with the safety concepts of automation technology and applicable standards.

Explanation of symbols used and signal words



This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety measures that follow this symbol to avoid possible injury or death.

There are three different categories of personal injury that are indicated with a signal word.

DANGER This indicates a hazardous situation which, if not avoided, will result in death or serious injury.

WARNING This indicates a hazardous situation which, if not avoided, could result in death or serious injury.

CAUTION This indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.



This symbol together with the signal word **NOTE** and the accompanying text alert the reader to a situation which may cause damage or malfunction to the device, hardware/software, or surrounding property.



This symbol and the accompanying text provide the reader with additional information or refer to detailed sources of information.

How to contact us

Internet

Up-to-date information on Phoenix Contact products and our Terms and Conditions can be found on the Internet at:

phoenixcontact.com

Make sure you always use the latest documentation.

It can be downloaded at:

phoenixcontact.net/products

Subsidiaries

If there are any problems that cannot be solved using the documentation, please contact your Phoenix Contact subsidiary.

Subsidiary contact information is available at phoenixcontact.com.

Published by

PHOENIX CONTACT GmbH & Co. KG
Flachsmarktstraße 8
32825 Blomberg
GERMANY

Should you have any suggestions or recommendations for improvement of the contents and layout of our manuals, please send your comments to:

tecdoc@phoenixcontact.com

Please observe the following notes

General terms and conditions of use for technical documentation

Phoenix Contact reserves the right to alter, correct, and/or improve the technical documentation and the products described in the technical documentation at its own discretion and without giving prior notice, insofar as this is reasonable for the user. The same applies to any technical changes that serve the purpose of technical progress.

The receipt of technical documentation (in particular user documentation) does not constitute any further duty on the part of Phoenix Contact to furnish information on modifications to products and/or technical documentation. You are responsible to verify the suitability and intended use of the products in your specific application, in particular with regard to observing the applicable standards and regulations. All information made available in the technical data is supplied without any accompanying guarantee, whether expressly mentioned, implied or tacitly assumed.

In general, the provisions of the current standard Terms and Conditions of Phoenix Contact apply exclusively, in particular as concerns any warranty liability.

This manual, including all illustrations contained herein, is copyright protected. Any changes to the contents or the publication of extracts of this document is prohibited.

Phoenix Contact reserves the right to register its own intellectual property rights for the product identifications of Phoenix Contact products that are used here. Registration of such intellectual property rights by third parties is prohibited.

Other product identifications may be afforded legal protection, even where they may not be indicated as such.

Caution: Installation only by qualified personnel

Installation, startup and maintenance of the product may only be performed by qualified specialist staff who have been authorized for this by the system operator. An electrician is a person who, because of their training, experience and instruction, and knowledge of relevant standards, can assess any required operations and recognize any possible dangers.

Specialist staff must read and understand this documentation and comply with instructions.

Observe the national regulations in force for the operation, functional testing, repairs and maintenance of electronic devices.

Table of contents

1	Factoryline SWITCH 2000 range	7
1.1	Properties and versions	7
1.1.1	Dimensions of the FL SWITCH 2000	8
1.1.2	Elements of the devices	9
1.1.3	Description of the combo ports	9
1.1.4	Status and diagnostic indicators	10
2	Mounting and installation	11
2.1	Mounting and removing the devices	11
2.2	Installing the devices	12
2.2.1	Connecting the supply voltage	12
2.2.2	Grounding ?	14
2.2.3	Assignment of the RJ45 Ethernet connectors	14
2.2.4	Use of SFP slots (principle)	14
2.2.5	Using the SD card	16
3	Startup and function	17
3.1	Delivery state/factory settings	17
3.2	Using Smart mode	17
3.2.1	Calling Smart mode	17
3.2.2	Factoryline SWITCH 2000 range3.2.2Selecting the desired setting	18
3.2.3	Possible operating modes in Smart mode	18
3.2.4	Exiting Smart mode	18
3.2.5	Operating with a default IP address	18
3.2.6	Operating in Unmanaged mode	19
3.3	Assigning IP parameters via BootP	19
3.3.1	Assigning the IP address using FL NETWORK MANAGER Basic	19
3.3.2	Assigning the IP address using IPAssign.exe	21
4	Frame switching	25
4.1	Store and forward	25
4.2	Multi-address function	25
4.2.1	Learning addresses	25
4.2.2	Prioritization	26
5	Configuration and diagnostics in web-based management	27
5.1	Requirements for the use of WBM	27
5.2	Functions/information in WBM	28
5.2.1	Information area of WBM	29

	5.2.2	Configuration area of WBM	33
	5.2.3	Diagnostics area of WBM	52
6		Configuration and diagnostics via Command Line Interface (CLI)	57
	6.1	Using the Command Line Interface (CLI).....	57
	6.2	Access to the CLI	57
	6.3	Basic principles for using CLI commands	58
	6.4	Command syntax	59
	6.5	Using the CLI Help.....	59
	6.6	Auto-completion of commands.....	60
	6.7	Using the CLI Network Scripting UI.....	61
7		Simple Network Management Protocol (SNMP)	63
	7.1	General function	63
8		Link Layer Discovery Protocol (LLDP)	65
	8.1	Basics.....	65
9		Multicast filtering	69
	9.1	Multicast Configuration.....	69
10		Virtual Local Area Network (VLAN)	71
11		Technical data and ordering data	75
	11.1	Technical data for devices in the 2000 version	75
	11.2	Technical data for devices in the 2100 version	76
	11.3	Technical data for devices in the 2200 version	78
	11.4	Technical data for devices in the 2300 version	81
	11.5	Ordering data	85
A		Appendix for document lists.....	89
	A 1	List of figures	89
	B 2	List of tables	93
	C 3	Index.....	95

1 Factoryline SWITCH 2000 range

1.1 Properties and versions

The Managed Switches in the 2000 version are Ethernet Switches which are suitable for industrial use. They are available in the following versions:

- With five 10/100 Mbps RJ45 ports (FL SWITCH 2005)
- With eight 10/100 Mbps RJ45 ports (FL SWITCH 2008)

The Managed Switches in the 2100 version are Gigabit Ethernet Switches which are suitable for industrial use. They are available in the following versions:

- With five 10/100/1000 Mbps RJ45 ports (FL SWITCH 2105)
- With eight 10/100/1000 Mbps RJ45 ports (FL SWITCH 2108)

The Managed Switches in the 2200 version are Ethernet Switches which are suitable for industrial use. They are available in the following versions:

- With five 10/100 Mbps RJ45 ports (FL SWITCH 2205)
- With eight 10/100 Mbps RJ45 ports (FL SWITCH 2208)
- With seven 10/100 Mbps RJ45 ports and one FO port in SC format for multimode (FL SWITCH 2207-FX)
- With seven 10/100 Mbps RJ45 ports and one FO port in SC format for single mode (FL SWITCH 2207-FX-SM)
- With six 10/100 Mbps RJ45 ports and two FO ports in SC format for multimode (FL SWITCH 2206-2FX)
- With six 10/100 Mbps RJ45 ports and two FO ports in SC format for single mode (FL SWITCH 2206-2FX SM)
- With six 10/100 Mbps RJ45 ports and two FO ports in ST format for multimode (FL SWITCH 2206-2FX ST)
- With six 10/100 Mbps RJ45 ports and two FO ports in ST format for single mode (FL SWITCH 2206-2FX SM ST)
- With four 10/100 Mbps RJ45 ports, two Fast Ethernet combo ports, and two SFX ports (FL SWITCH 2204-2TC-2SFX)
- With six 10/100 Mbps RJ45 ports and two SFX ports (FL SWITCH 2206-2SFX)

The Managed Switches in the 2300 version are Gigabit Ethernet Switches which are suitable for industrial use. They are available in the following versions:

- With eight 10/100/1000 Mbps RJ45 ports (FL SWITCH 2308)
- With four 10/100/1000 Mbps RJ45 ports, two Gigabit combo ports, and two SFP ports (FL SWITCH 2304-2GC-2SFP)
- With six 10/100/1000 Mbps RJ45 ports and two SFP ports (FL SWITCH 2306-2SFP)

1.1.1 Dimensions of the FL SWITCH 2000




Figure 1-1 Dimensions of the FL SWITCH 2000

1.1.2 Elements of the devices




Figure 1-2 Elements of the devices

Table 1-1

Number	Meaning
1	Connection for the supply voltage
2	RJ45 ports
3	Mode switch
4	Diagnostic and status indicators
5	Slot for optional SD card

1.1.3 Description of the combo ports

Combo ports enable a high degree of flexibility when setting up networks. They consist of a corresponding RJ45 port (e.g., X3.1) and a corresponding SFP port (e.g., X3.2). Only one port of the pair can be used at a time. Each combo port can therefore be used as a copper or fiberglass port. Inserting an SFP module disables the corresponding RJ45 port. If a combo port is used as a fiberglass port, the Link LED of the corresponding RJ45 port lights up orange when there is an active connection.

The following FL SWITCH 2000 versions have combo ports:

- FL SWITCH 2204-2TC-2SFX (2 Fast-Ethernet combo ports for 100 Mbps SFP modules, ports 3 and 7)
- FL SWITCH 2304-2GC-2SFP (2 Gigabit combo ports for 100 Mbps and 1000 Mbps SFP modules, ports 3 and 7)

1.1.4 Status and diagnostic indicators



Please note that the meaning of the LEDs differs in Smart mode (see “Using Smart mode” on page 17).

Des.	Color	Status	Meaning
US1	Green	On	Supply voltage 1 within the tolerance range
		Off	Supply voltage 1 too low
US2 (for 2200/2300 version only)	Green	On	Supply voltage 2 within the tolerance range
		Off	Supply voltage 2 too low
FAIL (for 2200/2300 version only)	Red	On	Digital alarm output floated, i.e., an error is present
		Off	Digital alarm output connected to ground potential (ground), i.e., an error is not present
LNK/ACT (at port top)	Green	On	Link active
		Flashing	Data transmission
		Off	Link not active
SPD (at port bottom)	Green/ orange	On	Green: 100 Mbps Orange (for 2100/2300 version only): 1000 Mbps
		Off	10 Mbps if Link LED is active

2 Mounting and installation

2.1 Mounting and removing the devices

Mount the device on a clean DIN rail according to DIN EN 50022 (e.g., NS 35 ... from Phoenix Contact). To avoid contact resistance, only use clean, corrosion-free DIN rails. End brackets (E/NS 35 N, Order No. 0800886) can be mounted to the right and left of the device to stop the modules from slipping on the DIN rail.

Mounting:

- Place the module onto the DIN rail from above (A1). The upper holding keyway of the module must be hooked onto the top edge of the DIN rail. Push the module from the front towards the mounting surface (A2).




Figure 2-1 Snapping the device onto the DIN rail

- Once the module has been snapped on properly, check that it is fixed securely on the DIN rail.

Removal:

- Pull down the positive latch using a suitable tool (e.g., screwdriver). The positive latch remains snapped out. Then swivel the bottom of the device away from the DIN rail slightly (B1). Next, lift the device upwards away from the DIN rail (B2).




Figure 2-2 Removing the device

2.2 Installing the devices

2.2.1 Connecting the supply voltage

The device is operated using a 24 V DC voltage, which is applied via COMBICON. For devices in the 2200/2300 version, the voltage can also be supplied redundantly (see Figure 2-4).



For devices in the 2200/2300 version: if redundant power supply monitoring is active (default setting), an error is indicated if only one voltage is applied. A bridge between US1 and US2 prevents this error message. It is possible to deactivate monitoring in web-based management or via SNMP.

Operation with one power supply




Figure 2-3 Operating the device with one power supply (example)

Redundant operation with two power supplies




Figure 2-4 Redundant operation with two power supplies (example)



Please note that load distribution does not take place. The power supply unit with the higher voltage will supply the device on its own.

2.2.1.1 Connecting a relay to the digital alarm output

The digital alarm output is an open drain output. In normal mode, the output is connected to ground potential. If an error/alarm is present, the output is floated.




Figure 2-5 Connecting a relay to the digital alarm output



Please note that the relay must be suitable for the operating voltage. Use the RIF-0-RPT-24DC/21 (Order No. 2903370), for example.

2.2.2 Grounding



Grounding protects people and machines against hazardous voltages. To avoid these dangers, as far as possible, correct grounding, taking the local conditions into account, is vital.

All Factoryline devices must be grounded so that any possible interference is shielded from the data telegram and discharged to ground potential. A conductor of at least 2.5 mm² must be used for grounding. Mount the module on a grounded DIN rail. The module is functional grounded by snapping it onto the DIN rail.

2.2.3 Assignment of the RJ45 Ethernet connectors



Please note that for operation with 1000 Mbps (Gigabit), cables with four twisted pairs (eight wires), which meet the requirements of CAT5e as a minimum, must be used.



Please note that only devices in the 2100/2300 version support Gigabit.

Table 2-1 Pin assignment of RJ45 connectors

Pin number	10Base-T/10 Mbps	100Base-T/100 Mbps	1000Base-T/1000 Mbps
1	TD+ (transmit)	TD+ (transmit)	BI_DA+ (bidirectional)
2	TD- (transmit)	TD- (transmit)	BI_DA- (bidirectional)
3	RD+ (receive)	RD+ (receive)	BI_DB+ (bidirectional)
4	-	-	BI_DC+ (bidirectional)
5	-	-	BI_DC- (bidirectional)
6	RD- (receive)	RD- (receive)	BI_DB- (bidirectional)
7	-	-	BI_DD+ (bidirectional)
8	-	-	BI_DD- (bidirectional)

2.2.4 Use of SFP slots (principle)

The SFP slots are used by SFP modules (FO fiberglass modules in SFP format). By selecting the SFP modules, the user can specify whether the switch has multimode or single-mode FO ports, for example.

The SFP modules are available separately as accessories, see “Technical data and ordering data” on page 75.

2.2.4.1 Elements of the SFP modules




Figure 2-6 Elements of the SFP modules

2.2.4.2 Mounting the SFP modules

Inserting the SFP modules

- Insert the SFP modules in the relevant slots on the switch.
- Ensure correct mechanical alignment of the SFP modules.



Figure 2-7 Inserting the SFP modules (example)

Removing the SFP modules

- Remove the FO connector before removing the SFP module.
- Turn the release latch to the side and pull out the SFP module.

2.2.5 Using the SD card

The switch is provided with a Phoenix Contact SD card, thereby enabling quick configuration. The slot for the SD card is located on the back of the device.



Figure 2-8 Position of the SD card slot

Automatically reading the configuration on the SD card

To automatically read the configuration on the SD card, make sure that the card is inserted when the switch is started. As soon as the boot process has been completed (indicated by the LEDs on the port going out), the configuration is applied in the internal switch memory and is active during operation. The SD card can then be removed. The configuration also remains active when the switch is restarted, provided an SD card is not inserted in the device.

3 Startup and function

3.1 Delivery state/factory settings

By default upon delivery or after the system is reset to the factory settings, the following functions and properties are available:

- The user name is: “admin”
- The password is: “private”
- All IP parameters are deleted. The switch has no valid IP address.
- The available RJ45 ports are set to auto negotiation and auto crossing
- All counters of the SNMP agent are reset
- The web server (HTTP) and SNMPv2 are activated
- CLI (Telnet) is activated
- Port mirroring and MRP are deactivated
- Rapid Spanning Tree (RSTP) is activated (as of firmware Version 2.01)
- The digital alarm output is an open drain output. In the event of redundant power supply, the output is connected to ground potential. If there is no redundant power supply, the output is floated.
- BootP for assigning IP parameters is activated
- The MAC address table does not contain any entries
- LLDP is activated
- DHCP server is deactivated

3.2 Using Smart mode

Smart mode enables the user to change the operating mode of the switch, without having access to one of the management interfaces.

The following setting options can be selected via Smart mode:

- Resetting the IP configuration
- Operating in EtherNet/IP mode
- Operating with a static IP address
- Operating in Unmanaged mode
- Reset to the factory settings

The Mode button is used to call/exit Smart mode and to select the desired setting. The four mode LEDs indicate the mode that is currently selected and that will apply when exiting Smart mode.

3.2.1 Calling Smart mode

- Following the switch boot phase, as soon as the LEDs of all ports go out, press and hold down the Mode button for more than five seconds. If Smart mode is active, the four LEDs of port X1 and X2 will flash. The active state is indicated alternately by the flashing of all four LEDs.
- When Smart mode is started, the switch is initially in the “Exit without changes” state.

3.2.2 Selecting the desired setting

- To select the various settings, press the Mode button briefly and select the desired operating mode (see Table “Operating modes in Smart mode” on page 18).

3.2.3 Possible operating modes in Smart mode

The switch supports the selection of the following operating modes in Smart mode:

Table 3-1 Operating modes in Smart mode

Mode	LED at port 1 top	LED at port 1 bottom	LED at port 2 top	LED at port 2 bottom
Exit Smart mode without changes	On	Off	Off	Off
Reset to the factory settings	Off	On	Off	Off
Set EtherNet/IP mode	Off	Off	On	Off
Operating with a default IP address	Off	On	On	Off
Reset the IP configuration	On	On	On	Off
Operating in Unmanaged mode	Off	On	Off	On

3.2.4 Exiting Smart mode

- To exit, press and hold down the Mode button for at least five seconds. The previously selected operating mode is saved and activated.

3.2.5 Operating with a default IP address

For operation with a default IP address, the device is assigned a fixed IP address. A DHCP server is activated on the switch and assigns an IP address to the connected PC via DHCP.



To start up the device with a default IP address, activate the “Operating with a static IP address” Smart mode as described in “Using Smart mode” on page 17.

- In the network settings on your PC, select the “Obtain an IP address automatically” option.



Deactivate all other network interfaces on your PC.

- Connect the switch to your PC.
- Select the “Operating with a default IP address” Smart mode as described in “Using Smart mode” on page 17.
- The switch assigns an IP address to the PC via DHCP.
- The switch can now be accessed via IP address “192.168.0.254”.

Set the desired IP address via web-based management.

3.2.6 Operating in Unmanaged mode

For operation in Unmanaged mode, the switch can also be used without an IP address. The switch adopts the static IP address 0.0.0.0. The subnet mask and gateway are also configured to 0.0.0.0. In this way, web-based management can no longer be accessed, and the switch no longer sends BootP and DHCP requests.

The main functions remain active in Unmanaged mode:

- Redundancy mechanisms for loop avoidance (RSTP, FRD, LTS)
- Functions for hardening the network (broadcast/multicast limiter)
- Functions for reducing the network load (IGMP snooping)

The functions must be configured in Managed mode and will remain active when switching to Unmanaged mode. Alternatively, Unmanaged mode can be activated using a configuration file and SD card.



Unmanaged mode can only be exited by switching to a different Smart mode or by resetting the switch to the factory settings.

3.3 Assigning IP parameters via BootP



BootP is activated by default.

For IP address assignment, the device uses the BootP protocol. Numerous BootP servers are available on the Internet. You can use any of these programs for address assignment.

This section explains IP address assignment using the “FL NETWORK MANAGER Basic” (Order No. 2702889) and “IP Assignment Tool” software tools from Phoenix Contact.

Notes on BootP

During initial startup, the device sends BootP requests without interruption until it receives a valid IP address. As soon as it receives a valid IP address, the device stops sending BootP requests.

After a restart, the device sends three BootP requests and will only then accept the old IP address if there is no BootP response.

3.3.1 Assigning the IP address using FL NETWORK MANAGER Basic

Requirements

The device is connected to a PC with a Microsoft Windows operating system and the FL NETWORK MANAGER has been successfully installed.

Step 1: parameterizing the BootP server

- Open the FL NETWORK MANAGER software
- Open a new project in the software

- Under Tools → Options, select the BOOTP/DHCP SERVER menu item
- Configure the network interface on your PC to which the device is connected and select “BootP” mode. You can also adjust the subnet mask and configure a default gateway.
- Click “OK” to confirm the parameterization




Figure 3-1 Settings for the BootP server

Step 2: starting the BootP server

- In your project in the BOOTP/DHCP SERVER window, click on the Play icon next to the selected network interface. The BootP server is now activated.
- BootP requests that are received are listed in the BOOTP/DHCP SERVER window in table format




Figure 3-2 BootP server

Step 3: inserting incoming BootP requests in the reservation list and assigning IP parameters

- If you would now like to assign IP parameters to a device, such as an IP address, subnet mask or default gateway, right-click on an incoming BootP request in the BOOTP/DHCP SERVER window and select “Add to BOOTP/DHCP reservations”.
- Now enter the IP address to be assigned in the BOOTP/DHCP reservations window. The IP parameters are immediately transferred to the device.

- You can check whether IP address assignment was successful in the “IP address” column in the BOOTP/DHCP SERVER window.




Figure 3-3 FL Network Manager with BootP/DHCP reservation list displayed



If required, the IP parameters set here can be changed in web-based management (see “Requirements for the use of WBM” on page 27).

3.3.2 Assigning the IP address using IPAssign.exe

Requirements

The device is connected to a computer with a Microsoft Windows operating system.

Step 1: downloading and executing the program

- On the Internet, select the link phoenixcontact.net/catalog.
- Follow further instructions in order to access the search field.
- Enter order number 2702323 in the search field, for example.

The BootP IP addressing tool can be found among the various product-related downloads.

- Double-click on the “IPAssign.exe” file.
- In the window that opens, click on the “Run” button.

Step 2: “IP Assignment Tool”

The program opens and the start screen of the addressing tool appears.

The program is mostly in English for international purposes. However, the program buttons change according to the country-specific settings.

The start screen displays the IP address of the PC. This helps when addressing the device in the following steps.

- Click on the “Next” button.

Step 3: “IP Address Request Listener”

All devices sending a BootP request are listed in the window which opens. These devices are waiting for a new IP address.




Figure 3-4 “IP Address Request Listener” window



The MAC address of the switch can be found on the sticker on the side.

In this example, the switch has MAC address 00.A0.45.04.08.A3.

- Select the device to which you want to assign an IP address.
- Click on the “Next” button.

Step 4: “Set IP Address”

The following information is displayed in the window which opens:

- IP address of the PC
- MAC address of the selected device
- IP parameters of the selected device (IP address, subnet mask, and gateway address)
- Any incorrect settings




Figure 3-5 “Set IP Address” window with incorrect settings

- Adjust the IP parameters according to your requirements.

If inconsistencies are no longer detected, a message appears indicating that a valid IP address has been set.

- Click on the “Next” button.

Step 5: “Assign IP Address”

The program attempts to transmit the set IP parameters to the device.




Figure 3-6 “Assign IP Address” window

Following successful transmission, the next window opens.

Step 6: completing IP address assignment

The window that opens informs you that IP address assignment has been successfully completed. It gives an overview of the IP parameters that have been transmitted to the device with the MAC address shown.

To assign IP parameters for additional devices:

- Click on the “Back” button.

To exit IP address assignment:

- Click on the “Finish” button.



If required, the IP parameters set here can be changed in web-based management (see Section “Network” on page 39).

4 Frame switching

The switch operates in store and forward mode. When receiving a data packet, the switch analyzes the source and destination addresses. The switch stores up to 8192 MAC addresses in its address table with an adjustable aging time of 10 to 825 seconds.

4.1 Store and forward

All data telegrams received by the switch are stored and checked for validity. Invalid or faulty data packets (> 1536 bytes or CRC errors) and fragments (< 64 bytes) are rejected. Valid data telegrams are forwarded by the switch.

4.2 Multi-address function

The switch learns all the source addresses for each port. Only packets with:

- Unknown source addresses
- A source address for this port or
- A multicast/broadcast address

in the destination address field are forwarded via the relevant port. The switch can learn up to 8192 addresses. This is important if more than one end device is connected to one or more ports. Several independent subnetworks can be connected to one switch.

4.2.1 Learning addresses

The switch independently learns the addresses for end devices, which are connected via this port, by evaluating the source addresses in the data telegrams. When the switch receives a data telegram, it forwards this data telegram to only that port that connects to the specified device (if the address could be learned beforehand).

The switch monitors the age of the learned addresses. The switch automatically deletes from its address table address entries that exceed a specific age (default: 40 seconds, adjustable from 10 to 825 seconds, aging time).



All learned entries are deleted on a restart.
A link down deletes all the entries of the affected port.



A list of detected MAC addresses can be found in the MAC address table. The MAC address table can be deleted via the “Clear” button.



The aging time is set using the “dot1dTpAgingTime” MIB object (OID 1.3.6.1.2.1.17.4.2). The available setting range is 10 - 825 seconds. For static configuration, an aging time of 300 seconds is recommended.

4.2.2 Prioritization

The switch supports eight priority queues (traffic classes according to IEEE 802.1Q) for adjusting the internal packet processing sequence. Data telegrams that are received are assigned to these classes according to their priority, which is specified in the VLAN/prioritization tag, where the value “0” in the tag indicates the lowest priority and the value “7” indicates the highest priority.

Processing rules

The switch controller in the device forwards received packets to the available receive queues according to the following decisions:

- BPDU packets are always assigned to the high-priority queue.
- Packets with VLAN/prioritization tag are forwarded according to the queues listed above.
- All remaining data is assigned to the low-priority queue.

4.2.2.1 Class of Service (CoS)

Class of Service refers to a mechanism used to take into consideration the value of the priority field (values 1 to 7) in VLAN data packets with a tag. The switch assigns the data streams in various processing queues, depending on the priority information contained in the CoS tag. The switch supports four internal processing queues.

4.2.2.2 Quality of Service (QoS)

Quality of Service affects the forwarding and handling of data streams and results in individual data streams being given differential treatment (usually preferential). QoS can be used, e.g., to guarantee a transmission bandwidth for individual data streams. The switch uses QoS in connection with prioritization.

5 Configuration and diagnostics in web-based management

The user-friendly web-based management (WBM) interface can be used to manage the switch from anywhere in the network using a standard browser (e.g., Internet Explorer 11). The configuration and diagnostic functions are clearly displayed on a graphical user interface. Every user with a network connection to the device has read/write access to that device via a browser. A wide range of information about the device itself, set parameters, and the operating state can be viewed.



Modifications to the device can only be made by entering the valid password. By default upon delivery, the user name is “admin” and the password is “private”.



For security reasons, we recommend changing the existing password to a new one known only to you.

5.1 Requirements for the use of WBM

As the web server operates using the Hyper Text Transfer Protocol, a standard browser can be used. Access is via the URL “http://IP address of the device”. Example: “http://172.16.29.112”. If the web server is set to the secure HTTPS protocol in WBM, access is via the URL “https://IP address of the device”. For full operation of the web pages, the browser must support JavaScript 1.2 and Cascading Style Sheets Level 1. We recommend the use of Microsoft Internet Explorer 11.



WBM can only be called using a valid IP address. By default upon delivery, the switch has no valid IP address (see “Assigning IP parameters via BootP” on page 19).



Device login is only possible if cookies are allowed in the browser settings.



Some functions are opened in pop-up windows. It is therefore only possible to use all of the functions if pop-ups are permitted in the browser settings.

In order to make changes, you must log into the device. To do so, click on the “Login” button. By default upon delivery, the user name is “admin” and the password is “private”.



Figure 5-1 Login window

5.2 Functions/information in WBM

WBM is split into the following areas:

- Information: general device information
- Configuration: device configuration
- Diagnostics: device-specific diagnostics



Figure 5-2 Start page for web-based management (example)

5.2.1 Information area of WBM

5.2.1.1 Help & Documentation




Figure 5-3 “Help & Documentation” web page

Here you will find useful information about using web-based management. On this page, the following files and software, which are supplied with the device, can be downloaded directly from the device:

- Description Files (SNMP)
- IP Assignment Tool (see “Assigning the IP address using FL NETWORK MANAGER Basic” on page 19)

5.2.1.2 Device Status

Here you will find general information about your device, such as the serial number, firm-ware version or hardware version.

Device Status	
Device Identification	
Vendor	: Phoenix Contact GmbH & Co. KG
Address	: D-32823 Blomberg
Phone	: +49 -(0)5235 -3-00
Internet	: www.PhoenixContact.com
Type	: FL SWITCH 2208
Order No	: 2702327
Serial No	: 2033403292
Firmware Version	: 1.00
Hardware Version	: 00
Bootloader Version	: 1.00
Device Name	:
Description	:
Physical Location	:
Contact	:
IP Address	: 192.168.0.101
Subnet Mask	: 255.255.0.0
Gateway	: 0.0.0.0
IP Address Assignment	: BootP
MAC Address	: 00:A0:45:D2:D0:30
System Status	
Date & time	:
Uptime	: 12 min, 54 sec
Alarm Output 1	: Failed

Figure 5-4 “Device Status” web page

5.2.1.3 Technical Data

Here you will find the technical data for your device, such as specifications for the power supply.

Technical Data	
Technical Data	
Degree of Protection	: IP 20, IEC 60529
Class of Protection	: Class3 VDE 0106, EN 61140
Mechanical Dimension	: 45 x 115 x 130 (width x height x depth in mm)
Weight	: 220 g
Power Supply	
Connection Type	: via COMBICON : cable diameter 1.5 mm ² maximum
Nominal Power Supply	: 24V DC
Voltage Range	: 18V DC to 32V DC
Current Consumption	: 180mA
Interfaces	
Ethernet Ports	: 8
For modifications to the “Technical Data” and additional information on the data sheet, please refer to our Product Webpage .	

Figure 5-5 “Technical Data” web page

5.2.1.4 Local Diagnostics

Here you will find a brief explanation of how to interpret the individual LEDs on the device.

Local Diagnostics	
Power Supply	
US1	: Supply Voltage 1 (green LED)
US2	: Supply Voltage 2 (green LED)
Alarm Output	
FAIL	: Alarm Output failed (red LED)
Ethernet	
PORT LED 1	: Link and Activity (Green LED)
PORT LED 2	: Speed 10/100 Mbit/s (LED off/green)

Figure 5-6 “Local Diagnostics” web page

5.2.1.5 Alarm & Events

You will find a list of alarms and events on this page. The entries in the “Event Table” are also retained after power up. The “Event Table” can be downloaded from the device in CSV format.

Alarm & Events		
Event Table		
Index	Event	System Uptime
1	Cold start.	0 sec
2	Configuration Loaded	0 sec
3	US 2 lost.	0 sec
4	Alarm output 1 Failed.	0 sec
5	Link up on port 1.	0 sec
6	LLDP new neighbour on Port 1.	0 sec
7	IP address changed on interface 1.	0 sec
8	Configuration saved successfully.	0 sec
9	Link up on port 8.	0 sec
10	LLDP new neighbour on Port 8.	0 sec
11	LLDP neighbour information changed on Port 8.	0 sec
12	Link down on port 8.	0 sec
13	LLDP neighbour lost on Port 8.	0 sec
14	Link up on port 8.	0 sec
15	LLDP new neighbour on Port 8.	0 sec
16	LLDP neighbour information changed on Port 8.	0 sec

System Uptime (?) 17 min, 35 sec
 Event Count (?) Loaded 173 events
 Event Table as CSV File (?)
 Clear Event Table (?)

Figure 5-7 “Alarm & Events” web page

5.2.1.6 Port Table

You will find a list of the current states of the individual ports on this page.

Clicking on the “Redundancy Port Table” button opens a table with information on the individual ports and their redundancy mechanism assignment.

Port Table				
Advanced Tables				
(?) Port Redundancy Table				
Physical Ports				
Interface/Port	Type	Status	Modus	
1	TX 10/100	enable	100 MBit/s FD	
2	TX 10/100	enable	Not connected	
3	TX 10/100	enable	100 MBit/s FD	
4	TX 10/100	enable	100 MBit/s FD	
5	TX 10/100	enable	Not connected	
6	TX 10/100	enable	Not connected	
7	TX 10/100	enable	Not connected	
8	TX 10/100	enable	100 MBit/s FD	

Figure 5-8 “Port Table” web page

5.2.1.7 MAC Address Table

You will find a list of the current devices in the network on this page. The list can be downloaded from the device in CSV format.

MAC Address Table				
No.	VLAN	MAC-Address	Port	
1	1	00:0B:5D:C7:AE:28	4	
2	1	00:A0:45:D8:2C:D6	4	
3	1	00:A0:45:D8:30:C3	8	
4	1	00:A0:45:D8:37:3B	3	
5	1	00:A0:45:DE:96:22	1	
6	1	00:A0:45:DE:96:27	1	

MAC Table as CSV File [\(?\)](#)
 Clear MAC Table [\(?\)](#)

Figure 5-9 “MAC Address Table” web page

5.2.2 Configuration area of WBM

5.2.2.1 System

Reset Device: clicking on the “Reset” button restarts the device. All unsaved parameters will be lost.

The screenshot shows the 'System' configuration page with the following sections:

- Reset Device:** A 'Reset Device (?)' label and a 'Reset' button.
- Firmware Update:** A 'Firmware Update (?)' label and an 'Update Firmware' link.
- Configuration Handling:**
 - 'Status of Current Configuration (?)' with the value 'Configuration saved'.
 - 'SD Card State (?)' with the value 'No SD card present'.
 - 'Perform Action (?)' with a dropdown menu.
 - 'Perform Configuration Action (?)' with a dropdown menu.
 - 'Advanced Configuration (?)' with a link to 'Further configuration handling options'.
 - 'Secure UIs (?)' with a link to 'Security Context'.
- Administrator Password:**
 - 'Username (?)' with the value 'admin'.
 - 'Administrator Password (?)' with an empty password field.
 - 'Retype Password (?)' with an empty password field.
- Device Identification:**
 - 'Device Name (?)' with an empty text field.
 - 'Device Description (?)' with an empty text field.

At the bottom right, there are three buttons: 'Apply', 'Revert', and 'Apply&Save'.

Figure 5-10 “System” web page



The connection to the device is interrupted for the boot phase.

Firmware Update

Clicking on the “Update Firmware” link opens a pop-up in which the parameters for the firmware update must be entered.

Pop-up: Update Firmware

Update via HTTP: select “HTTP” as the method. Clicking on “Browse” allows you to select the desired file on your PC. Clicking on “Apply” starts the update.




Figure 5-11 “Firmware Update via HTTP” pop-up

Update via TFTP: select “TFTP” as the method.




Figure 5-12 “Firmware Update via TFTP” pop-up

- TFTP server IP address:
Here, set the IP address of the computer on which the TFTP server is active.
- Remote firmware filename:
Here, set the name of the firmware file which is to be transferred to the device.

- Automatic reboot after upload:
Here, set whether a reboot should be carried out after the firmware update. The firmware update starts as soon as you click on “Apply”.

Configuration Handling

Status of Current Configuration: indicates the status of the active configuration

SD Card State: indicates whether or not an SD card is inserted



This display can only be refreshed by reloading the web page.

Perform Action:

- Compare: compares the configuration file on the SD card with the one on the device.
- Clear: deletes the configuration file on the SD card.

The selected action is performed by clicking in the drop-down list.

Perform Configuration Action:

- Factory Default: resets the device configuration to the delivery state.
- Save Configuration: saves the active device configuration to the SD card.
- Reload Configuration: loads the configuration file from the SD card and applies it. The device is then restarted.

The selected action is performed by clicking in the drop-down list.

Advanced Configuration: clicking on the “Further configuration handling options” link opens a window in which the parameters for transferring a configuration file from the device to the PC (download) or from the PC to the device (upload) must be entered.

Secure UIs: clicking on the “Security Context” link opens the “Security Context” pop-up (see page 37).

Pop-up: Advanced Configuration

File Type: select the file type here.

Direction: here you should select whether the configuration is to be uploaded to or downloaded from the device.

Update status: indicates the current transfer status.

Start transfer: click on the “Start” button to start the transfer of the configuration.

Configuration name: here you should enter the name under which you want to save the configuration on the PC.

Transfer via HTTP: select “HTTP” as the transfer method. Clicking on “Browse” allows you to select the desired file on your PC. You can upload the desired file directly to the PC via your browser by selecting “HTTP Upload”.




Figure 5-13 “Advanced Configuration” pop-up

Transfer via TFTP: select “TFTP” as the transfer method.

TFTP server IP address: here you should enter the IP address via which the TFTP server can be reached.

Remote filename: here you should enter the name of the file to be uploaded or downloaded.

Figure 5-14 “Advanced Configuration” pop-up

Pop-up: Security Context

Create new context: clicking on the “Generate” button creates all the necessary keys and certificates for operation with HTTPS and SSH.

Current state: displays the status of the current availability of the security context.

Root CA: clicking on the “cacert.cer” link loads the Root CA certificate for the installation in the browser.

Advanced Configuration: clicking on the “File transfer” link opens the “Advanced Configuration” pop-up (see “Pop-up: Advanced Configuration” on page 35).

Figure 5-15 “Security Context” pop-up

Administrator Password

Figure 5-16 “Administrator Password” configuration area

You can change the administrator password here. The new password must be between 8 and 63 characters long. The new password will be activated after logout. By default upon delivery, the password is “private” (please note that it is case-sensitive). For security reasons, the input fields do not display your password, but instead “*****” is displayed.

Device Identification

Device information can be configured in this area, which is then displayed on the “Device Status” page.

Device Name: you can configure the device name here.

Device Description: you can enter a device description in this text field.

Physical Location: here you can provide the location of the device, such as the building in which it is installed.

Device Contact: you can enter a contact address in this field.

5.2.2.2 Quick Setup

The basic settings can be made in Quick Setup.

Figure 5-17 “Quick Setup” web page

Automation Profile: select a profile which is optimized for the desired operating mode.

IP Assignment: select the type of IP address assignment.

- STATIC: static IP address
- BOOTP: assignment via the Bootstrap protocol
- DHCP: assignment via a DHCP server

IP address: set the desired IP address.

Network mask: set the desired subnet mask here.

Default gateway: set the desired default gateway here.

Administrator password: you can change the administrator password here.

Device Name: you can enter the device name of the switch here.

Device Description: you can enter a description for the device here.

Physical Location: you can enter a location for the device here.

Device Contact: you can enter the name of a contact person for the device here.

LLDP Mode: you can enable or disable LLDP here.

- Disable: LLDP is deactivated
- Enable: LLDP is activated
- Send only: received LLDP BPDUs are ignored
- Receive only: no LLDP BPDUs are sent

The “LLDP Topology” link opens the corresponding page which can also be accessed via the menu item of the same name (see “Link Layer Discovery Protocol (LLDP)” on page 65).



Port-based LLDP configuration can be found on the “Service” page (see “Service” on page 40).

5.2.2.3 Network

The basic network settings are made here.

Figure 5-18 “Network” web page

IP Address Assignment: select the type of IP address assignment.

- STATIC: static IP address
- BOOTP: assignment via the Bootstrap protocol
- DHCP: assignment via a DHCP server

If you have chosen “STATIC”, now make the following settings:

IP Address: set the desired IP address.

Network Mask: set the desired subnet mask here.

Default Gateway: set the desired default gateway here.

Management VLAN: set the VLAN here, in which the management is to be located (default: "1").

ACD Mode: you can enable/disable the "Address Conflict Detection" function here.

ACD Status Information: clicking on the link opens the "Device Status" page.

ACD Conflict State	: No Conflict
ACD Conflict IP Address	: 0.0.0.0
ACD Conflict MAC Address	: 00:00:00:00:00:00

Figure 5-19 ACD status information on the "Device Status" page

5.2.2.4 Service




Figure 5-20 "Service" web page

Web Server: you can enable/disable the web server function and select the mode (HTTP/HTTPS) here.

SNMP Server: you can enable/disable the SNMP server function and the mode (SNMP v2, SNMP v3) here.

CLI Service:

- Disable: entry of CLI commands is deactivated
- Telnet: entry of CLI commands via Telnet is activated
- SSH: entry of CLI commands via Secure Shell (SSH) is activated

CLI Network Scripting UI:

- Disable: transmission of CLI commands via the network is deactivated
- Enable: transmission of CLI commands via the network is activated



For additional information on using the CLI, refer to "Configuration and diagnostics via Command Line Interface (CLI)" on page 57.

LLDP Mode:

- Disable: LLDP is disabled
- Enable: LLDP is enabled
- Send only: only LLDP BPDUs are sent.
- Receive only: only LLDP BPDUs are received.



Port-based LLDP configuration can be found on the “Service” page (see “Service” on page 40).

LLDP Transmit Interval: here you can set the interval in which LLDP telegrams are to be sent. The value must be between 5 and 32786 seconds (default: 5 s).

LLDP Transmission: you can enable/disable port-specific forwarding of LLDP telegrams here

LLDP Reception: you can enable/disable port-specific ignoring of LLDP telegrams here



For additional information on “LLDP”, refer to “Link Layer Discovery Protocol (LLDP)” on page 65.

5.2.2.5 Port Configuration

Individual Port Configuration

Figure 5-21 “Port Configuration” web page

Port: select the port that you want to configure individually.

Status: the port can be activated/deactivated here.

Name: you can assign the port a name.

Type: describes the physical properties of the port.

Link: displays the current link status of the port.

Negotiation Mode: indicates the current auto negotiation status.

Speed: displays the current transmission speed at which the port is operating.

Duplex: displays the transmission mode of the port.

Mode: the port can be set to a fixed speed and transmission mode here.

Link Monitoring: here you can set whether the link behavior is to be monitored at the selected port.

Default Priority: set the priority for incoming data packets at this port here.

Flow Control: flow control for the selected port can be enabled and disabled here.

Advanced Port Configuration

Clicking on the “Configure all ports simultaneously” link takes you to the “Port Configuration Table” page. You can set the status, mode, link monitoring, and flow control for all ports here.

Port Configuration Table			
Interface/Port	Status	Mode	Flow Control
1	Enable	Auto	Disable
2	Enable	Auto	Disable
3	Enable	Auto	Disable
4	Enable	Auto	Disable
5	Enable	Auto	Disable
6	Enable	Auto	Disable
7	Enable	Auto	Disable
8	Enable	Auto	Disable

Figure 5-22 “Port Configuration Table” web page

Clicking on the “Configure Port Mirroring” button takes you to the port mirroring configuration (see “Port Mirroring” on page 53).

Clicking on the “Configure Port Settings for a VLAN” button takes you to the “VLAN Port Configuration” page (see “VLAN Configuration” on page 71).

5.2.2.6 VLAN Configuration

For additional information on “VLAN”, refer to “Virtual Local Area Network (VLAN)” on page 71.

VLAN Configuration

VLAN Mode (?) Tagged

Static VLANs

Static VLAN Configuration Webpages (?) [Static VLAN Configuration](#)
[VLAN Port Configuration](#)
[VLAN Port Configuration Table](#)

VLAN Diagnostic

VLAN Diagnostic Webpages (?) [Current VLANs](#)

Figure 5-23 “VLAN Configuration” web page

5.2.2.7 Multicast Filtering

Figure 5-24 “Multicast Filtering” web page

For additional information on “Multicast”, refer to “Multicast filtering” on page 69.

5.2.2.8 Network Redundancy

Spanning-Tree Configuration

Figure 5-25 “Spanning-Tree Configuration” configuration area

RSTP Mode:

- Disable: the RSTP function is not activated
- 802.1w: the RSTP function is activated globally and operates according to standard 802.1w



The functions below are only available if “802.1w” is activated.

- Large Tree Support: the “Large Tree Support” option makes the ring topology suitable for 28 switches along the relevant path if RSTP is used. The “Large Tree Support” option could provide an RSTP ring topology with up to 57 devices.
- Fast Ring Detection: this function speeds up switch-over to a redundant path in the event of an error and provides easy diagnostics. RSTP fast ring detection provides each ring with an ID. This ID is made known to each switch in the relevant ring. A switch can belong to several different rings at the same time.
- Bridge Priority: the bridge and backup roots can be specified via “Bridge Priority”. Only multiples of 4096 are permitted. The value will be rounded automatically to the next multiple of 4096. Once you have clicked on “Apply&Save”, the initialization mechanism is started (default value: 32768).
- Bridge Hello Time: specifies the time interval within which the root bridge regularly reports to the other switches via BPDU.
- Bridge Forward Delay: the bridge forward delay value indicates how long the switch is to wait for the port state in STP mode to change from “Discarding” to “Listening” and from “Listening” to “Learning” (2 x forward delay).
- Bridge Max Age: the parameter is set by the root switch and used by all switches in the ring. The parameter is sent to make sure that each switch in the network has a constant value, against which the age of the saved configuration is tested.

Clicking on the “RSTP Port Configuration” button takes you to the “RSTP Port Configuration” pop-up.

Clicking on the “RSTP Port Configuration Table” button takes you to the “RSTP Port Configuration Table” pop-up (see page 47).

Clicking on the “RSTP Diagnostic” button opens the “RSTP Diagnostic” page as a pop-up (see page 52).

Media Redundancy Protocol (MRP)

MRP device mode:

- Disable: the MRP function is not activated
- Client: the MRP function is activated and the switch is the client
- Manager: the MRP function is activated and the switch is the ring manager



The manager function is only available for the 2200/2300 versions provided that the SD card is inserted and has a MRP master license (MRM) (see “Ordering data” on page 85).

Ring Port 1: select the first MRP ring port here

Ring Port 2: select the second MRP ring port here

Pop-up: RSTP Port Configuration

RSTP Port Configuration

Select Port (?) port-1

RSTP Enable (?) enable

Admin Path Cost (?) 0

Operating Path Cost (?) 200000

Auto Edge (?) enable

Admin Edge (?) Non-Edge

Operating Edge (?) Edge

Priority (?) 128

Forward Transitions (?) 1

Designated Root (?) 8000.00:A0:45:D2:D0:30

Designated Bridge (?) 8000.00:A0:45:D2:D0:30

Designated Port ID (?) 8001

Designated Cost (?) 0

Protocol Version (?) RSTP

Apply Revert Apply&Save

Figure 5-26 “RSTP Port Configuration” web page

Select Port: select the port for which you want to change the RSTP settings here.

RSTP Enable:

- Enable: RSTP is activated for the port
- Disable: RSTP is deactivated for the port

Admin Path Cost: displays the path costs set for this port. A path cost equal to “0” activates the cost calculation according to the transmission speed (10 Mbps = 2000000; 100 Mbps = 200000).

Operating Path Cost: displays the path costs used for this port.

Auto Edge: here you can set whether an automatic change from non-edge port to edge port is to be carried out after a link up.

Admin Edge: here you can set whether this port is to be operated as an edge port (default setting), if possible.

Operating Edge: indicates whether this port is operated as an edge port or a non-edge port.

Priority: indicates the priority set for this port (default value: 128).

Forward Transitions: indicates the number of times the port switches from the “Discarding” state to the “Forwarding” state.

Designated Root: indicates the root bridge for this spanning tree.

Designated Bridge: indicates the switch from which the port receives the best BPDUs.

Designated Port ID: indicates the port via which the BPDUs are sent from the designated bridge. The value is based on the port priority (2 digits) and the port number.

Designated Cost: displays the path costs of this segment to the root switch.

Protocol Version: displays the protocol version.

Pop-up: RSTP Port Configuration Table

RSTP Port Configuration Table			
Port	RSTP Enable	Admin Edge	Admin Cost
1	enable	Non-Edge	0
2	enable	Non-Edge	0
3	enable	Non-Edge	0
4	enable	Non-Edge	0
5	enable	Non-Edge	0
6	enable	Non-Edge	0
7	enable	Non-Edge	0
8	enable	Non-Edge	0

Figure 5-27 “RSTP Port Configuration Table” web page

Port: indicates the ports for which RSTP is available.

RSTP Enable: here you can individually activate or deactivate RSTP for each port.

Admin Edge: here you can set whether this port is to be operated as an edge port (default setting), if possible.

Admin Cost: displays the path costs set for this port. A path cost equal to “0” activates the cost calculation according to the transmission speed (10 Mbps = 2000000; 100 Mbps = 200000).

5.2.2.9 Security

Security
UI Security Secure UIs (?) Security Context

Figure 5-28 “Security” web page

Secure UIs: clicking on the “Security Context” link opens the pop-up of the same name (see page 37).

5.2.2.10 DHCP Service




Figure 5-29 “DHCP Service” web page

DHCP Mode: select the DHCP service you wish to use here.

- None: a DHCP service is not used on the switch.
- Relay Agent: the DHCP relay agent (DHCP Option 82) is enabled.
- Server: the switch is used as the DHCP server.



The following fields are only available after selecting “Relay Agent” as the DHCP mode.

Option82: select the address which should be used as the remote ID here.

- IP: uses the IP address of the switch as the remote ID.
- MAC: uses the MAC address of the switch as the remote ID.

Server IP Address: set the IP address of the DHCP server in your network here.

Port Mode: select the ports for which the DHCP relay agent should be activated here.



The following fields are only available after selecting “Server” as the DHCP mode.

- Running State: shows the current status of the DHCP server. The status is “Inactive” if some setting options are incorrect.
- Pool Start Address: set the first IP address of the DHCP server address pool here.
- Pool Size: set the number of IP addresses in the DHCP server address pool here. Please note that the number of IP addresses must match the configured subnetwork.
- Network Mask: set the subnet mask that is assigned to the DHCP clients here.
- Router IP: set the router/default gateway IP address that is assigned to the DHCP clients here.
- DNS IP: set the DNS IP address that is assigned to the DHCP clients here.

- Lease Time (s): the time that the DHCP server leases an IP address to a client before it has to report to the server again can be set here. The value must be between 300 and 2592000 seconds, "0" is interpreted as an infinite time (default: 3600).
- Accept Bootp: here you can set whether the switch acting as the DHCP server accepts BootP requests. If this function is activated, an IP address with an infinite lease time is assigned to the requesting DHCP clients.

Port-based DHCP Configuration: opens the "Port-based DHCP Configuration" pop-up.
 Current DHCP leases: opens the "Current DHCP Leases" pop-up where the IP addresses that are currently assigned are displayed.

DHCP static leases: opens the "DHCP Static Leases" pop-up for configuring static IP address assignment.

Pop-up: Port-based DHCP Configuration

The port-based DHCP server functionality can be configured in this pop-up.

- Select Port: select the port for which you wish to carry out port-based DHCP server configuration here.
- Local Service enable: activate the port-based DHCP server functionality for the selected port here.
- Local IP: enter the IP address that is assigned to the client at the selected port here.
- Netmask: enter the subnet mask that is assigned to the client at the selected port here.
- Router: enter the gateway address that is assigned to the client at the selected port here.
- DNS: enter the DNS address that is assigned to the client at the selected port here.




Figure 5-30 "DHCP Port Local Service" pop-up

Pop-up: Current DHCP Leases

This pop-up displays the IP addresses that are currently assigned.

- Leased IP: displays the assigned IP addresses.
- Client ID: displays the MAC address of the client to which the IP address is assigned.
- System Uptime: displays the time that has elapsed since the IP address was assigned to the client.
- Local Port: indicates the port to which the client is connected.
- State: indicates the status of the client.
- Lease count: displays the number of assigned IP addresses.

- Release: clicking on the “Release” button releases unused entries.

Pop-up: DHCP Static Leases

This pop-up displays the configured static IP assignment.

Lease list:

- IP address: displays the static IP address assigned.
- Client address: displays the MAC address of the client.
- Delete: clicking on the red cross deletes the entry.

Create new static entry:

- IP address: enter the static IP address that you wish to assign here.
- Client address: enter the MAC address to which you wish to assign a static IP address here.
- Create: click on the “Create” button to carry out static assignment.

Clear static table: click on the “Clear” button to delete all the static DHCP leases.

5.2.2.11 Local Events




Figure 5-31 “Local Events” web page

Alarm output 1:

Here you can activate the digital alarm output and read the current status (if a red “o” is present, this event has occurred).

Events: here you can determine under which conditions a digital alarm output should report an error.

- Power Supply lost: in the event that US1 or US2 is lost
- Monitored link down: under “Advanced”, select the ports to which link down behavior should be reported.
- MRP Ring Failure: indicates an error message in the event of an MRP ring error.

- Pluggable Memory missing: an error message is generated if no memory card is present.

5.2.2.12 Quality of Service

Broadcast Limiter

Broadcast: the broadcast limiter can be activated or deactivated here.

Broadcast Threshold: set the threshold value in frames per second for the broadcast limiter here. The entered value is rounded down to the next valid value.

Multicast: the multicast limiter can be activated or deactivated here.

Multicast Threshold: set the threshold value in frames per second for the multicast limiter here. The entered value is rounded down to the next valid value.

Unknown Unicast: the limiter for unknown unicasts can be activated or deactivated here. Unicasts of a MAC address that has been learned by the switch are not affected.

Unicast Threshold: set the threshold value in frames per second for the limiter of unknown unicasts here. The entered value is rounded down to the next valid value.

Flow Control

Port Configuration: clicking on the “Configure Flow Control per port” link opens the “Port Configuration” web page, which contains the configuration options for flow control.

Port Configuration Table: clicking on the “Configure Flow control for multiple ports at once” link opens the “Port Configuration Table” web page where flow control can be configured for all ports.




Figure 5-32 “Quality of Service” web page

5.2.3 Diagnostics area of WBM

5.2.3.1 LLDP Topology

For additional information, please refer to “Link Layer Discovery Protocol (LLDP)” on page 65.

5.2.3.2 RSTP Diagnostic



Figure 5-33 “RSTP Diagnostic” web page

Designated Root: indicates the root bridge for this spanning tree.

Root Port: indicates the port to which the root is connected. If the root is not directly connected, it shows the direction of the root.

Root Cost: displays the total path costs for the root.

Topology Changes: indicates the number of topology changes.

Last Topology Change: indicates when the last topology change took place.

Hello Time: shows the hello time set at the root.

Forward Delay: shows the forward delay set at the root.

Max Age: shows the max age time set at the root.

Clicking on the “Redundancy Port Table” button opens a table with information on the individual ports and their redundancy mechanism assignment.

5.2.3.3 MRP Diagnostic

Operating Mode: indicates the current MRP device status.

MRP Manager Function: indicates whether an MRP manager license (MRM) is available.



The following fields are only available after selecting “Manager” as the operating mode.

Ring Status: indicates the current status of the MRP ring.

Change Counter: indicates the number of changes in state in the MRP ring.
 Clicking on the “Redundancy Port Table” button opens a table with information on the individual ports and their redundancy mechanism assignment.



Figure 5-34 “MRP Diagnostic” web page

5.2.3.4 Current VLANs

For additional information, refer to “Current VLANs” on page 74.

5.2.3.5 Current Multicast Groups

For additional information, refer to “Multicast filtering” on page 69.

5.2.3.6 Port Mirroring




Figure 5-35 “Port Mirroring” web page

Global Status:

- Enable: port mirroring is activated globally
- Disable: port mirroring is deactivated globally

Destination Port: select the port to which the measuring device (PC) is connected here.

Mirrored Ports (Ingress): specify the ports from which the incoming data traffic should be mirrored here.

Mirrored Ports (Egress): specify the ports from which the outgoing data traffic should be mirrored here.

5.2.3.7 Trap Manager




Figure 5-36 “Trap Manager” web page

Trap Mode:

- Enable: sending of SNMP traps is enabled
- Disable: sending of SNMP traps is disabled

Trap Server: all trap servers which are to receive SNMP traps from this device are displayed here.

Add Trap Server: enter the IP address of a trap server and click on “Add&Save” to create this trap server.

Test Trap Connection: the connection to the trap server is tested by clicking on the “Send Trap” button.

The table lists the SNMP traps which can be sent by the device. Here you can select the actions for which SNMP traps should be sent.

5.2.3.8 Port Counter




Figure 5-37 “Port Counter” web page

Here you will find an overview of the port statistics.

5.2.3.9 Port Utilization




Figure 5-38 “Port Utilization” web page

Here you will find an overview of the port utilization for this device as a percentage. For a detailed overview, click on the graph of an individual port.

5.2.3.10 SFP Diagnostics

Interface/Port	Type	Serial No	RX Power(dBm)	TX Power(dBm)
5	NO SFP			
6	NO SFP			
7	FL SFP SX 1000(MM)	003043001197	-16.9	-6.2
8	NO SFP			

Figure 5-39 “SFP Diagnostics” web page

Here you will find an overview of the SFP ports.

Interface/Port: the ports that can be used with SFP modules are displayed here. Clicking on a port number opens the port configuration for that port.

Type: the type of SFP module used is displayed here. If no SFP module is inserted, “NO SFP” is displayed.

Serial No: the serial number of the SFP module used is displayed in this column.

RX Power (dBm): the incoming power level is displayed in this column.

TX Power (dBm): the outgoing power level is displayed in this column.

6 Configuration and diagnostics via Command Line Interface (CLI)

6.1 Using the Command Line Interface (CLI)

The Command Line Interface (CLI) is a text-based tool that can be used to configure and diagnose the switch. The CLI is accessed by means of a connection via Telnet (factory default) or SSH. The configuration of the CLI service via the switch's web-based management is described in "Assigning IP parameters via BootP" on page 19.

6.2 Access to the CLI

The CLI is accessed via a Telnet connection (factory default) or SSH connection from a management host, e.g., a PC. For example, the Windows command prompt or the PuTTY freeware tool can be used as an input terminal.

The switch requires an IP address and a subnet mask in order to access the CLI. The configuration of the switch network parameters is described in "Assigning IP parameters via BootP" on page 19 and "Network" on page 39.




Figure 6-1 Configuration of a Telnet connection in PuTTY



Figure 6-2 Command terminal in PuTTY




Figure 6-3 Establishing a Telnet connection via Windows command prompt




Figure 6-4 Command terminal in Windows command prompt

6.3 Basic principles for using CLI commands

In this section, the **CLI command names** are written in bold. *CLI parameters* are written in italics and must be replaced by appropriate values (e.g., names or numbers). If a command has several parameters, the order of these must be strictly observed.

The parameters of a command may be mandatory, optional or a selection of values (see Table “Structure of CLI commands” on page 58).

Table 6-1 Structure of CLI commands

Symbol	Example	Description
< > Angle brackets	<Value>	Denotes a mandatory parameter that must be entered in place of the brackets
[] Square brackets	[Value]	Denotes an optional parameter that can be entered in place of the brackets
{ } Braces	{choice1 choice2}	Denotes the mandatory selection of a value from a given list of values
Vertical bar	choice1 choice2	Separates mutually exclusive selection options
[{ }] Braces within square brackets	[{choice 1 choice 2}]	Denotes a selection within an optional parameter

6.4 Command syntax

A command consists of one or more terms which can be followed by one or more parameters. These parameters can be mandatory or optional values.

Some commands, e.g., **show network** or **clear config**, do not require parameters. Other commands, e.g., **network parms**, require values to be specified after the command name. The parameters must be entered in the specified order, whereby optional parameters always follow mandatory parameters.

The following example illustrates the syntax using the command **network parms**:

network parms <ipaddr> <netmask> [gateway]

- **network parms** is the command name.
- <ipaddr> and <netmask> are parameters and represent mandatory values, which must be specified after the entry of the command name.
- [gateway] is an optional parameter, which means that a value does not have to be specified.

The following examples illustrate the correct syntax for entering the **network parms** command:

network parms 192.168.10.42 255.255.255.0

network parms 192.168.10.42 255.255.255.0 192.168.10.0

The following examples illustrate incorrect syntax for entering the **network parms** command:

network parms 192.168.10.42 - missing mandatory parameter

network parms 255.255.255.0 - missing mandatory parameter

network parms 255.255.255.0 192.168.10.42 - incorrect parameter sequence

6.5 Using the CLI Help

Entering a question mark (?) in the command prompt displays a list of all the commands currently available together with a brief description.

Table 6-2 Structure of CLI commands

Command	Description
?	Display available commands

Typing a question mark (?) after each entry displays all the available command names or parameters from this point on.

```
>spanning-tree

port          Configure spanning tree port parameter.
max-age       Configure bridge maximum aging time.
fwd-delay     Configure bridge forward delay.
hello-time    Configure bridge hello time.
bdg-prio      Configure bridge priority.
frd           Configure fast ring detection.
lts           Configure large tree support.
status        Select spanning tree status.

>spanning-tree bdg-prio
```

If the Help output displays a parameter in angle brackets, this parameter must be replaced by a value. Example:

<ipaddr> Enter the IP address

```
>network parms

<ipaddress>      Enter IP address.

>network parms 192.168.10.43
```

If at any point there are no further command names or parameters available or further parameters are optional, the following message appears in the output prompting you to execute the command that was entered:

<cr> Press Enter to execute the command

```
>show mrp

<cr>              Press Enter to execute the command.

>show mrp

OK
```

6.6 Auto-completion of commands

The Autocomplete command is an additional way of writing a command, provided enough letters have already been entered to clearly identify the command name. As soon as enough letters have been entered, press space or TAB to automatically complete the words.

```
>spanning-tree f
  2 Possibilities:
    fwd-delay
    frd
>spanning-tree fwd-delay
```

6.7 Using the CLI Network Scripting UI

The CLI Network Scripting UI enables CLI commands from scripts to be loaded onto the switch via the network. This means that the switch can be configured and diagnosed using a URL via PC or from a controller. Each command that is entered is confirmed by the switch, either with OK (config commands) or by outputting the switch data (show commands).

The command entry must follow a specific syntax:

`http://ipaddress/php/command.php?usr=username&pwd=password&cmd=cli_command_1 | cli_command_2 | ...`

The following examples illustrate the correct syntax for entering commands via the CLI Network Scripting UI:

Example: changing the device name


`http://192.168.10.42/php/command.php?usr=admin&pwd=private&cmd=device-identity name Switch2000`



OK

Example: displaying the network parameters and changing the user password

`http://192.168.10.42/php/command.php?usr=admin&pwd=private&cmd=show network | users passwd private2`



OK IP Assignment : bootp IP Address : 192.168.10.42 Network Mask : 255.255.255.0 Default Gateway : 0.0.0.0 Management VLAN : 1 ACD Mode : None ERROR

7 Simple Network Management Protocol (SNMP)

7.1 General function

SNMP is a non-proprietary standard for network management. It defines commands for reading and writing information, and defines formats for error and status messages. SNMP is also a structured model that consists of agents, their relevant Management Information Base (MIB), and a manager. The manager is a software tool that is executed on a network management station. The agents are located inside switches, bus terminals, routers, and other devices that support SNMP. The task of the agents is to collect and provide data in the MIB. The manager regularly requests and displays this information. The devices can be configured by writing data from the manager to the MIB. In the event of an emergency, the agents can also send messages (traps) directly to the manager.



All configuration modifications, which are to take effect after a device restart, must be saved permanently using the “flWorkFWCtrlConfSave” object.

SNMP interface

All managed Factoryline components have an SNMP agent. The agent of this type of device manages the following MIBs (Management Information Bases):

- FL Managed Infrastructure MIB
- lldpMIB
- RFC1213 MIB
- rmon
- snmpMIB
- ifMIB
- snmpFrameworkMIB
- etherMIB
- pBridgeMIB
- qBridgeMIB
- dot1dBridge
- rstpMIB
- IP MIB

Network management stations, such as a PC with a MIB browser, can read and modify configuration and diagnostic data from network devices via the Simple Network Management Protocol. In addition, any SNMP tools or network management tools can be used to access Factoryline products via SNMP. To do this, the MIBs supported by the relevant device must be made available to the SNMP management tools.

On the one hand, these are globally valid MIBs, which are specified and described in RFCs (Requests for Comments). This includes, for example, MIB2 according to RFC1213, which is supported by all SNMP-compatible network devices. On the other hand, manufacturers can specify their own SNMP objects, which are then assigned to a private manufacturer area in the large SNMP object tree. Manufacturers are then responsible for their own private (enterprise) areas, i.e., they must ensure that only one object (object name and parameters)

is assigned to an object ID and can be published. If an object is no longer needed, it can be labeled as “expired”, but it cannot be reused with other parameters under any circumstances.

Phoenix Contact provides notification of ASN1 SNMP objects by publishing their descriptions on the Internet.

Reading SNMP objects is not password-protected. However, a password is required for read access in SNMP, but this is set to “public”, which is usual for network devices, and cannot be modified. By default upon delivery, the password for write access is “private” and can be changed by the user.



SNMP and the web interface use the same password, which can be changed by the user.

Use of SNMPv3

When using SNMPv3, several points must be observed when accessing the SNMP objects. In contrast to SNMPv2, SNMPv3 is a secure protocol via which the message content and the passwords are transmitted in encrypted form.

To use SNMPv3, the switch must first be configured accordingly (see “Service” on page 40). In addition, you need to change the MIB browser to SNMPv3 and create an SNMPv3 user with the following parameters:

- MD5 as the algorithm for authentication
- DES as the algorithm for privacy
- User name: “admin”
- Password: current device password (Note: the password must be at least 8 characters long. If the default password is “private”, “private_” must be used for access.).

Another benefit for the user is the option of sending traps using the Simple Network Management Protocol.

Management Information Base (MIB)

Description which contains all the data (objects and variables) required for network management.

Agent

An agent is a software tool which collects data from the network device on which it is installed and transmits this data on request. Agents reside in all managed network components and transmit the values of specific settings and parameters to the management station. On a request of a manager or on the occurrence of a specific event, the agent transmits the collected information to the management station.



Not all devices support all object classes. If an unsupported object class is requested, an error message is generated. If an attempt is made to modify an unsupported object class, an error message is also generated.

The descriptions of the individual SNMP objects are located in the respective MIBs and can be downloaded from the Phoenix Contact e-shop. Note that the MIB is located in a firm-ware’s respective software package (zip file).

8 Link Layer Discovery Protocol (LLDP)

8.1 Basics

LLDP

The switch supports LLDP according to IEEE 802.1ab and enables topology detection of devices that also have LLDP activated.

Advantages of using LLDP:

- Improved error location detection
- Improved device replacement
- More efficient network configuration

The following information is received by or sent to neighbors, as long as LLDP is activated:

- The device transmits its own management and connection information to neighboring devices.
- The device receives management and connection information from neighboring devices.

Displaying LLDP information

The information that is collected is presented in a table in WBM. The table includes the two port numbers that are used to connect both devices together, as well as the IP address, the device name of neighboring devices, and the device type.



Please note that a blocking port using RSTP does not receive LLDP BPDUs, but does send them.

LLDP general

The Link Layer Discovery Protocol (LLDP) according to 802.1ab is used by network devices to learn and maintain the individual neighborhood relationships.

Function

A network infrastructure component transmits a port-specific BPDU (Bridge Protocol Data Unit), which contains the individual device information, at the “Message Transmit Interval” to each port in order to distribute topology information. The peer connected to the relevant port learns the corresponding port-specific neighbors from these BPDUs.

The information learned from the BPDUs is saved for a defined period of time known as the TTL (Time To Live) value. Subsequent receipt of the same BPDUs increases the TTL value again and the information is still saved. When the TTL elapses, the neighbor information is deleted.



The switch manages a maximum of 50 items of neighborhood information, all other information is ignored.



If several neighbors are displayed on one switch port, then at least **one other** switch/hub, which does not support or has not activated LLDP, is installed **between** this switch and the neighbor indicated.

Table 8-1 Event table for LLDP

Event	Activity of the individual LLDP agent	Response of the neighboring LLDP agent
Activate LLDP agent or device startup	Transmit LLDP BPDUs to all ports	Include sender in the list of neighbors
Deactivate LLDP agent or software reset	Transmit LLDP BPDUs with a TTL value of 0 seconds to all ports	Delete sender from the list of neighbors
Link up	Transmit port-specific LLDP BPDUs	Include sender in the list of neighbors
Link down	Delete all neighbors for this port	-
Timer (Message Transmit Interval)	Cyclic transmission of BPDUs to all ports	Update information
Aging (Time To Live)	Delete neighborhood information	-
Receiving a BPDU from a new neighbor	Extend list of neighbors and respond with port-specific BPDU	Include sender in the list of neighbors

**Link Layer
Discovery Protocol**




Figure 8-1 “Link Layer Discovery Protocol” web page

For devices in the 2000/2100 version, LLDP can be activated or deactivated globally for all ports. Devices in the 2200/2300 version also offer a port-based configuration option for sending and receiving LLDP telegrams.

The LLDP can be configured on the “Service” page in WBM (see “Service” on page 40).

LLDP topology

LLDP Topology			
Local Port	Chassis ID	IP Address	Remote Port
1	00:A0:45:DE:96:22	192.168.0.100	Port 5
3	00:A0:45:D8:37:3A	0.0.0.0	Port 1
4	00:A0:45:D8:2C:D2	192.168.10.42	Port 4
8	00:A0:45:D8:30:C2	192.168.10.202	Port 1

Figure 8-2 “LLDP Topology” web page

A table is created for known neighbors and contains the following four columns:

- Local Port
Contains the port number of the local switch that is used to connect a neighbor to this switch.
- Chassis ID
MAC address of the connected neighboring device
- IP address
Indicates the management IP address of the neighbor.
- Remote Port
Indicates the port number of the neighboring switch that is used to connect the neighbor to the local switch.

9 Multicast filtering

9.1 Multicast Configuration

9.1.0.1 Multicast Filtering

Figure 9-1 “Multicast Filtering” web page

IGMP Snooping:

- disable: the “IGMP Snooping” function is disabled
- enable: the “IGMP Snooping” function is enabled

Snoop Aging Time: the snoop aging time can be set here. The snoop aging time is the time period during which membership reports are expected from the querier. If no membership reports are received during this time, the associated ports are deleted from the multicast groups. The value must be between 30 and 3600 (default: 300).

IGMP Query Version: you can set the IGMP query version which the switch should use to send the queries here.

Query Interval: set the interval in which the switch should send the queries here.

Current Querier: displays the IP address of the current querier in the network.

Extension FUQ (Forward Unknown to Querier): select here whether a multicast group should be created for unknown multicast packets which forwards the packets in the direction of the querier.

Extension BUQ (Block Unknown at Querier): select here whether unknown multicast packets should be blocked at the querier.

Auto Query Ports: here you can set whether automatic selection of additional query ports is activated. Ports are automatically integrated in every multicast group. In the case of redundancy switch-over, the multicast packets are not blocked because the ports required are already members of the multicast group.

Clear AQP: button for deleting the ports that are automatically assigned to the groups.

Static Query Ports: select which ports are static query ports.

Clicking on the “Current multicast groups” link opens the “Current Multicast Groups” web page as a pop-up.



The device can manage up to 50 dynamic multicast groups.

Current Multicast Groups		
VLAN ID	Multicast Address	Port Member
1	01:00:5e:00:01:81	56
1	01:00:5e:40:0e:c1	56
1	01:00:5e:40:0f:00	56
1	01:00:5e:7f:ff:fa	6, 56

Figure 9-2 “Current Multicast Groups” web page

10 Virtual Local Area Network (VLAN)

10.0.0.1 VLAN Configuration




Figure 10-1 “VLAN Configuration” web page

VLAN Mode:

- Transparent: in “Transparent” mode, the switch processes the incoming data packets as described in the “Frame switching” section. Neither the structure nor the contents of the data packets are changed. The information about VLAN assignment from a tag that may be contained in the data packet is ignored.
- Tagged: in “Tagged” mode, the switch forwards the data packets depending on the VLAN assignment.

Clicking on the “Static VLAN Configuration” button takes you to the “Static VLAN Configuration” page. Up to 8 (2000/2100 version) or up to 32 (2200/2300 version) static VLANs can be set up here.

Pop-up: Static VLAN Configuration




Figure 10-2 “Static VLAN Configuration” web page

List of Static VLANs: all VLANs created up to this point are displayed here.

VLAN ID: set the VLAN ID which you wish to assign to the new VLAN here. The value must be between 2 and 4094.

VLAN Name: specify the name of the VLAN which you wish to create here.

VLAN Memberships: specify which ports should be located in the VLAN.

- T: tagged port
- U: untagged port
- -: not a member of the VLAN

Use the “Delete” button to delete the VLAN selected in the list.



VLAN 1 cannot be deleted.

Clicking on the “VLAN port configuration” button takes you to the “VLAN Port configuration” page.

Pop-up: VLAN Port configuration

VLAN Port configuration

Port Number (?) port-1

Default VLAN ID (?) 1

Default Priority (?) 0

Ingress Filter (?) disable

Apply Revert Apply&Save

Figure 10-3 “VLAN Port configuration” web page

Port number: enter the port for which you wish to change the VLAN settings.
Default VLAN ID: set the VLAN ID to which the port should be assigned here.
Default Priority: set the VLAN priority for the selected port here.
Ingress Filter: set here whether the ingress filter should be activated.
Clicking on the “VLAN Port Table” button takes you to the VLAN port table.

Pop-up: VLAN Port Configuration Table

VLAN Port Configuration Table

Port	Default VLAN	Default Priority	Ingress Filter
1	1	0	disable
2	1	0	disable
3	1	0	disable
4	1	0	disable
5	1	0	disable
6	1	0	disable
7	1	0	disable
8	1	0	disable


Apply Revert Apply&Save

Figure 10-4 “VLAN Port Configuration Table” web page

Clicking on the “Current VLANs” link opens the “Current VLANs” web page as a pop-up.

Current VLANs

This page lists the current VLANs and displays the ports for each VLAN, which are either “Tagged” or “Untagged”.



VLAN ID	Type	Untagged Member	Tagged Member
1	Static	1, 2, 3, 4, 5, 6, 7, 8	

Figure 10-5 “Current VLANs” web page

11 Technical data and ordering data

11.1 Technical data for devices in the 2000 version

General data	
Function	Ethernet/Fast Ethernet Switch; conforms to standard IEEE 802.3/802.3u
Switch principle	Store and forward
Address table	8192 MAC addresses
SNMP	Version 2c, Version 3
Transmission capacity per port 64-byte packet size, half duplex	At 10 Mbps: 14880 pps (packets per second) At 100 Mbps: 148800 pps
Supported MIBs	MIB II and private SNMP objects from Phoenix Contact
Housing dimensions (width x height x depth) in mm	45 x 130 x 115 (depth from top edge of DIN rail)
Permissible operating temperature	0°C to 60°C
Permissible storage temperature	-40°C to +85°C
Degree of protection	IP20 (not assessed in compliance with UL, assessed by PTL), IEC 60529
Protection class	Class 3 VDE 0106; IEC 60536, for inside use only
Humidity	
Operation	10% to 95%, non-condensing
Storage	10% to 95%, non-condensing
Air pressure	
Operation	86 kPa to 108 kPa, 1500 m above sea level
Storage	66 kPa to 108 kPa, 3500 m above sea level
Ambient compatibility	Free from substances that would hinder coating with paint or varnish according to VW specification
Mounting position	Perpendicular to a standard DIN rail
Connection to protective earth ground	Snapped onto a grounded DIN rail
Pollution degree	2
Overvoltage category	None
Weight	Up to 220 g, typical
Supply voltage (US)	
Connection	Via COMBICON; maximum conductor cross section = 1.5 mm ² , use copper wires that are suitable for 75°C or equivalent
Nominal value	24 V DC
Permissible voltage range	18 V DC to 32 V DC
Permissible ripple (within the permissible voltage range)	3.6 V _{PP}
Current consumption at US for 18 V DC, maximum	300 mA (FL SWITCH 2005) 350 mA (FL SWITCH 2008)
Current consumption at US for 24 V DC, maximum	165 mA (FL SWITCH 2005) 180 mA (FL SWITCH 2008)
Test voltage	170 V DC for one minute
Interfaces	
Number of Ethernet ports	5 / 8

Ethernet interfaces

Properties of the RJ45 ports

Number	Up to 8 with auto crossing and auto negotiation
Connection format	8-pos. RJ45 socket on the switch
Connection medium	Twisted pair cable
Cable impedance	100 ohms
Transmission speed	10/100 Mbps
Maximum network segment expansion	100 m

Mechanical tests

Shock testing according to IEC 60068-2-27	Operation: 30g, half-sine shock pulse
Vibration resistance according to IEC 60068-2-6	Operation/storage/transport: 2g, 10 Hz - 150 Hz
Free fall according to IEC 60068-2-32	1 m

Conformance with EMC Directives

Developed according to IEC 61000-6-2	
Noise emission according to EN 55022: 1998 + A1: 2000 + A2: 2003 (interference voltage)	Class A (industrial applications)
Noise emission according to EN 55011: 1998 + A1: 1999 + A2: 2002 (electromagnetic interference)	Class A (industrial applications)
Noise immunity according to EN 61000-4-2 (IEC 1000-4-2) (ESD) Contact discharge: Air discharge: Indirect discharge:	Requirements according to DIN EN 61000-6-2 Test intensity 3, criterion B Test intensity 3, criterion A Test intensity 3, criterion A
Noise immunity according to EN 61000-4-3 (IEC 1000-4-3) (electromagnetic fields)	Requirements according to DIN EN 61000-6-2 Test intensity 3, criterion A
Noise immunity according to EN 61000-4-6 (IEC 1000-4-6) (conducted)	Requirements according to DIN EN 61000-6-2 Test intensity 3, criterion A
Noise immunity according to EN 61000-4-4 (IEC 1000-4-4) (burst) Data cables: Power supply:	Requirements according to DIN EN 61000-6-2 Test intensity 3, criterion A Test intensity 3, criterion A
Noise immunity according to EN 61000-4-5 (IEC 1000-4-5) (surge) Data cables: Power supply:	Requirements according to DIN EN 61000-6-2 Test intensity 2, criterion A Test intensity 1, criterion A

Additional certifications

RoHS

11.2 Technical data for devices in the 2100 version

General data

Function	Ethernet/Fast Ethernet/Gigabit Switch; conforms to standard IEEE 802.3/802.3u/802.3ab
Switch principle	Store and forward
Address table	8192 MAC addresses

General data	
SNMP	Version 2c, Version 3
Transmission capacity per port 64-byte packet size, half duplex	At 10 Mbps: 14880 pps (packets per second) At 100 Mbps: 148800 pps At 1000 Mbps: 1488100 pps
Supported MIBs	MIB II and private SNMP objects from Phoenix Contact
Housing dimensions (width x height x depth) in mm	45 x 130 x 115 (depth from top edge of DIN rail)
Permissible operating temperature	0°C to 60°C
Permissible storage temperature	-40°C to +85°C
Degree of protection	IP20 (not assessed in compliance with UL, assessed by PTL), IEC 60529
Protection class	Class 3 VDE 0106; IEC 60536, for inside use only
Humidity	
Operation	10% to 95%, non-condensing
Storage	10% to 95%, non-condensing
Air pressure	
Operation	86 kPa to 108 kPa, 1500 m above sea level
Storage	66 kPa to 108 kPa, 3500 m above sea level
Ambient compatibility	Free from substances that would hinder coating with paint or varnish according to VW specification
Mounting position	Perpendicular to a standard DIN rail
Connection to protective earth ground	Snapped onto a grounded DIN rail
Pollution degree	2
Overvoltage category	None
Weight	Up to 240 g, typical

Supply voltage (US)	
Connection	Via COMBICON; maximum conductor cross section = 1.5 mm ² , use copper wires that are suitable for 75°C or equivalent
Nominal value	24 V DC
Permissible voltage range	18 V DC to 32 V DC
Permissible ripple (within the permissible voltage range)	3.6 V _{PP}
Current consumption at US for 18 V DC, maximum	350 mA (FL SWITCH 2105) 400 mA (FL SWITCH 2108)
Current consumption at US for 24 V DC, maximum	225 mA (FL SWITCH 2105) 275 mA (FL SWITCH 2108)
Test voltage	170 V DC for one minute

Interfaces	
Number of Ethernet ports	5 / 8

Ethernet interfaces	
Properties of the RJ45 ports	
Number	Up to 8 with auto crossing and auto negotiation
Connection format	8-pos. RJ45 socket on the switch
Connection medium	Twisted pair cable

Ethernet interfaces (Fortsetzung)

Cable impedance	100 ohms
Transmission speed	10/100/1000 Mbps
Maximum network segment expansion	100 m

Mechanical tests

Shock testing according to IEC 60068-2-27	Operation: 30g, half-sine shock pulse
Vibration resistance according to IEC 60068-2-6	Operation/storage/transport: 2g, 10 Hz - 150 Hz
Free fall according to IEC 60068-2-32	1 m

Conformance with EMC Directives

Developed according to IEC 61000-6-2	
Noise emission according to EN 55022: 1998 + A1: 2000 + A2: 2003 (interference voltage)	Class A (industrial applications)
Noise emission according to EN 55011: 1998 + A1: 1999 + A2: 2002 (electromagnetic interference)	Class A (industrial applications)
Noise immunity according to EN 61000-4-2 (IEC 1000-4-2) (ESD) Contact discharge: Air discharge: Indirect discharge:	Requirements according to DIN EN 61000-6-2 Test intensity 3, criterion B Test intensity 3, criterion A Test intensity 3, criterion A
Noise immunity according to EN 61000-4-3 (IEC 1000-4-3) (electromagnetic fields)	Requirements according to DIN EN 61000-6-2 Test intensity 3, criterion A
Noise immunity according to EN 61000-4-6 (IEC 1000-4-6) (conducted)	Requirements according to DIN EN 61000-6-2 Test intensity 3, criterion A
Noise immunity according to EN 61000-4-4 (IEC 1000-4-4) (burst) Data cables: Power supply:	Requirements according to DIN EN 61000-6-2 Test intensity 3, criterion A Test intensity 3, criterion A
Noise immunity according to EN 61000-4-5 (IEC 1000-4-5) (surge) Data cables: Power supply:	Requirements according to DIN EN 61000-6-2 Test intensity 2, criterion A Test intensity 1, criterion A

Additional certifications

RoHS	@EEE 2002/95/EC - WEEE 2002/96/EC CE
------	---

11.3 Technical data for devices in the 2200 version

General data

Function	Ethernet/Fast Ethernet Switch; conforms to standard IEEE 802.3/802.3u
Switch principle	Store and forward
Address table	8192 MAC addresses
SNMP	Version 2c, Version 3
Transmission capacity per port 64-byte packet size, half duplex	At 10 Mbps: 14880 pps (packets per second) At 100 Mbps: 148800 pps
Supported MIBs	MIB II and private SNMP objects from Phoenix Contact
Housing dimensions (width x height x depth) in mm	45 x 130 x 115 (depth from top edge of DIN rail)

General data	
Permissible operating temperature	-40°C to 70°C
Permissible storage temperature	-40°C to +85°C
Degree of protection	IP20 (not assessed in compliance with UL, assessed by PTL), IEC 60529
Protection class	Class 3 VDE 0106; IEC 60536, for inside use only
Humidity	
Operation	10% to 95%, non-condensing
Storage	10% to 95%, non-condensing
Air pressure	
Operation	68 kPa to 108 kPa, 3000 m above sea level
Storage	66 kPa to 108 kPa, 3500 m above sea level
Ambient compatibility	Free from substances that would hinder coating with paint or varnish according to VW specification
Mounting position	Perpendicular to a standard DIN rail
Connection to protective earth ground	Snapped onto a grounded DIN rail
Pollution degree	2
Overvoltage category	None
Weight	Up to 260 g, typical

Supply voltage (US1/US2 redundant)	
Connection	Via COMBICON; maximum conductor cross section = 1.5 mm ² , use copper wires that are suitable for 75°C or equivalent
Nominal value	24 V DC
Permissible ripple (within the permissible voltage range)	3.6 V _{PP}
Permissible voltage range	9 V DC to 57 V DC for the following devices FL SWITCH 2205 FL SWITCH 2208 FL SWITCH 2207-FX FL SWITCH 2207-FX SM FL SWITCH 2206-2FX FL SWITCH 2206-2FX SM FL SWITCH 2206-2FX ST FL SWITCH 2206-2FX SM ST
Permissible voltage range	12 V DC to 57 V DC for the following devices FL SWITCH 2204-2TC-2SFX FL SWITCH 2206-2SFX
Current consumption at US for 9 V DC , maximum (without digital output)	1.2 A (FL SWITCH 2205) 1.3 A (FL SWITCH 2208) 1.4 A (FL SWITCH 2207-FX) 1.4 A (FL SWITCH 2207-FX SM) 1.5 A (FL SWITCH 2206-2FX) 1.5 A (FL SWITCH 2206-2FX SM) 1.5 A (FL SWITCH 2206-2FX ST) 1.5 A (FL SWITCH 2206-2FX SM ST)

FL SWITCH 2000

Supply voltage (US1/US2 redundant) (Fortsetzung)

Current consumption at US for 12 V DC, maximum (without digital output)	1.4 A (FL SWITCH 2204-2TC-2SFX) 1.4 A (FL SWITCH 2206-2SFX)
Current consumption at US for 24 V DC, maximum (without digital output)	170 mA (FL SWITCH 2205) 190 mA (FL SWITCH 2208) 220 mA (FL SWITCH 2207-FX) 220 mA (FL SWITCH 2207-FX SM) 260 mA (FL SWITCH 2206-2FX) 260 mA (FL SWITCH 2206-2FX SM) 260 mA (FL SWITCH 2206-2FX ST) 260 mA (FL SWITCH 2206-2FX SM ST) 250 mA (FL SWITCH 2204-2TC-2SFX) 230 mA (FL SWITCH 2206-2SFX)
Test voltage	170 V DC for one minute

Interfaces

Number of Ethernet ports	5 / 8
Digital alarm output	
Voltage	12 - 58 V DC
Current carrying capacity	100 mA, typical/0.7 A, maximum (1 minute)

Ethernet interfaces

Properties of the RJ45 ports

Number	Up to 8 with auto crossing and auto negotiation
Connection format	8-pos. RJ45 socket on the switch
Connection medium	Twisted pair cable
Cable impedance	100 ohms
Transmission speed	10/100 Mbps
Maximum network segment expansion	100 m

Properties of the fiberglass ports

Number	Up to 2
Connection format	SC/ST/SFX format (depending on the device used)
Connection medium	Fiberglass
Connecting plug	SC/ST/LC format (depending on the device used)
Transmission speed	100 Mbps
Maximum network segment expansion	Depends on the SFP module/fiber type used
Fiber type	Depends on the SFP module/fiber type used
Laser protection class	1
Wavelength	850/1310 nm (depending on the device/SFP module used)

Properties of the combo ports

Number	Up to 2
Transmission speed	100 Mbps
Wavelength	Depends on the SFP module used
Maximum transmission length	Depends on the SFP module used

Mechanical tests

Shock testing according to IEC 60068-2-27

Operation: 30g,
half-sine shock pulse

Vibration resistance according to IEC 60068-2-6

Operation/storage/transport: 5g, 10 Hz - 150 Hz

Free fall according to IEC 60068-2-32

1 m

Conformance with EMC Directives

Developed according to IEC 61000-6-2

Noise emission according to EN 55022: 1998
+ A1: 2000 + A2: 2003 (interference voltage)

Class A (industrial applications)

Noise emission according to EN 55011: 1998
+ A1: 1999 + A2: 2002 (electromagnetic interference)

Class A (industrial applications)

Noise immunity according to EN 61000-4-2 (IEC 1000-4-2) (ESD)

Contact discharge:

Air discharge:

Indirect discharge:

Requirements according to DIN EN 61000-6-2

Test intensity 3, criterion B

Test intensity 3, criterion A

Test intensity 3, criterion A

Noise immunity according to EN 61000-4-3 (IEC 1000-4-3)
(electromagnetic fields)

Requirements according to DIN EN 61000-6-2

Test intensity 3, criterion A

Noise immunity according to EN 61000-4-6 (IEC 1000-4-6) (conducted)

Requirements according to DIN EN 61000-6-2

Test intensity 3, criterion A

Noise immunity according to EN 61000-4-4 (IEC 1000-4-4) (burst)

Data cables:

Power supply:

Requirements according to DIN EN 61000-6-2

Test intensity 3, criterion A

Test intensity 3, criterion A

Noise immunity according to EN 61000-4-5 (IEC 1000-4-5) (surge)

Data cables:

Power supply:

Requirements according to DIN EN 61000-6-2

Test intensity 2, criterion A

Test intensity 1, criterion A

Additional certifications

RoHS

@EEE 2002/95/EC - WEEE 2002/96/EC

IECEX:

IEC 60079-0:2011, 6th Edition

IEC 60079-15:2010, 4th Edition

ATEX:

EN 60079-0:2012+A11:2013

EN 60079-15:2010

Field of application:

II 3 G Ex nA IIC T4 Gc

IECEX ULD 16.0018X

CE

11.4 Technical data for devices in the 2300 version

General data

Function

Ethernet/Fast Ethernet/Gigabit Switch; conforms to standard
IEEE 802.3/802.3u/802.3ab

Switch principle

Store and forward

Address table

8192 MAC addresses

FL SWITCH 2000

General data	
SNMP	Version 2c, Version 3
Transmission capacity per port 64-byte packet size, half duplex	At 10 Mbps: 14880 pps (packets per second) At 100 Mbps: 148800 pps At 1000 Mbps: 1488100 pps
Supported MIBs	MIB II and private SNMP objects from Phoenix Contact
Housing dimensions (width x height x depth) in mm	45 x 130 x 115 (depth from top edge of DIN rail)
Permissible operating temperature	-40°C to 70°C
Permissible storage temperature	-40°C to +85°C
Degree of protection	IP20 (not assessed in compliance with UL, assessed by PTL), IEC 60529
Protection class	Class 3 VDE 0106; IEC 60536, for inside use only
Humidity	
Operation	10% to 95%, non-condensing
Storage	10% to 95%, non-condensing
Air pressure	
Operation	53 kPa to 108 kPa, 5000 m above sea level
Storage	53 kPa to 108 kPa, 5000 m above sea level
Ambient compatibility	Free from substances that would hinder coating with paint or varnish according to VW specification
Mounting position	Perpendicular to a standard DIN rail
Connection to protective earth ground	Snapped onto a grounded DIN rail
Pollution degree	2
Overvoltage category	None
Weight	Up to 310 g, typical
Supply voltage (US1/US2 redundant)	
Connection	Via COMBICON; maximum conductor cross section = 1.5 mm ² , use copper wires that are suitable for 75°C or equivalent
Nominal value	24 V DC
Permissible voltage range	12 V DC to 57 V DC
Permissible ripple (within the permissible voltage range)	3.6 V _{PP}
Current consumption at US for 12 V DC, maximum	1.4 A (FL SWITCH 2308) 1.5 A (FL SWITCH 2304-2GC-2SFP) 1.5 A (FL SWITCH 2306-2SFP)
Current consumption at US for 24 V DC, maximum	280 mA (FL SWITCH 2308) 290 mA (FL SWITCH 2304-2GC-2SFP) 280 mA (FL SWITCH 2306-2SFP)
Test voltage	170 V DC for one minute
Interfaces	
Number of Ethernet ports	8
Digital alarm output	
Voltage	12 - 57 V DC
Current carrying capacity	100 mA, maximum 700 mA / 1 minute

Ethernet interfaces

Properties of the RJ45 ports

Number	Up to 8 with auto crossing and auto negotiation
Connection format	8-pos. RJ45 socket on the switch
Connection medium	Twisted pair cable
Cable impedance	100 ohms
Transmission speed	10/100/1000 Mbps
Maximum network segment expansion	100 m

Properties of the fiberglass ports

Number	Up to 2
Connection format	Gigabit SFP format
Connection medium	Fiberglass
Connecting plug	LC format (SFP module)
Transmission speed	100/1000 Mbps (depending on the SFP module used)
Maximum network segment expansion	Depends on the SFP module/fiber type used
Fiber type	Depends on the SFP module used
Laser protection class	1
Wavelength	850/1310/1550 nm (depending on the device/SFP module used)

Properties of the combo ports

Number	Up to 2
Transmission speed	100/1000 Mbps
Wavelength	Depends on the SFP module used
Maximum transmission length	Depends on the SFP module used

Mechanical tests

Shock testing according to IEC 60068-2-27	Operation: 30g, half-sine shock pulse
Vibration resistance according to IEC 60068-2-6	Operation/storage/transport: 5g, 10 Hz - 150 Hz
Free fall according to IEC 60068-2-32	1 m

Conformance with EMC Directives

Developed according to IEC 61000-6-2	
Noise emission according to EN 55022: 1998 + A1: 2000 + A2: 2003 (interference voltage)	Class A (industrial applications)
Noise emission according to EN 55011: 1998 + A1: 1999 + A2: 2002 (electromagnetic interference)	Class A (industrial applications)
Noise immunity according to EN 61000-4-2 (IEC 1000-4-2) (ESD) Contact discharge: Air discharge: Indirect discharge:	Requirements according to DIN EN 61000-6-2 Test intensity 3, criterion B Test intensity 3, criterion A Test intensity 3, criterion A
Noise immunity according to EN 61000-4-3 (IEC 1000-4-3) (electromagnetic fields)	Requirements according to DIN EN 61000-6-2 Test intensity 3, criterion A

Conformance with EMC Directives

Noise immunity according to EN 61000-4-6 (IEC 1000-4-6) (conducted)

Requirements according to DIN EN 61000-6-2
Test intensity 3, criterion A

Noise immunity according to EN 61000-4-4 (IEC 1000-4-4) (burst)

Data cables:
Power supply:

Requirements according to DIN EN 61000-6-2
Test intensity 3, criterion A
Test intensity 3, criterion A

Noise immunity according to EN 61000-4-5 (IEC 1000-4-5) (surge)

Data cables:
Power supply:

Requirements according to DIN EN 61000-6-2
Test intensity 2, criterion A
Test intensity 1, criterion A

Additional certifications

RoHS

@EEE 2002/95/EC - WEEE 2002/96/EC
IECEX:
IEC 60079-0:2011, 6th Edition
IEC 60079-15:2010, 4th Edition

ATEX:
EN 60079-0:2012+A11:2013
EN 60079-15:2010

Field of application:
II 3 G Ex nA IIC T4 Gc
IECEX ULD 16.0018X



Differences between this version and previous versions of the user manual

Rev. 00: initial version

Rev. 01: devices added

11.5 Ordering data

Products

Description	Order designation	Order No.	Pcs./Pkt.
Managed Switch with five 10/100 Mbps RJ45 ports	FL SWITCH 2005	2702323	1
Managed Switch with eight 10/100 Mbps RJ45 ports	FL SWITCH 2008	2702324	1
Managed Switch with five 10/100/1000 Mbps RJ45 ports	FL SWITCH 2105	2702665	1
Managed Switch with eight 10/100/1000 Mbps RJ45 ports	FL SWITCH 2108	2702666	1
Managed Switch with five 10/100 Mbps RJ45 ports	FL SWITCH 2205	2702326	1
Managed Switch with eight 10/100 Mbps RJ45 ports	FL SWITCH 2208	2702327	1
Managed Switch with seven 10/100 Mbps RJ45 ports and one FO port in SC format for multimode	FL SWITCH 2207-FX	2702328	1
Managed Switch with seven 10/100 Mbps RJ45 ports and one FO port in SC format for single mode	FL SWITCH 2207-FX SM	2702329	1
Managed Switch with six 10/100 Mbps RJ45 ports and two FO ports in SC format for multimode	FL SWITCH 2206-2FX	2702330	1
Managed Switch with six 10/100 Mbps RJ45 ports and two FO ports in SC format for single mode	FL SWITCH 2206-2FX SM	2702331	1
Managed Switch with six 10/100 Mbps RJ45 ports and two FO ports in ST format for multimode	FL SWITCH 2206-2FX ST	2702332	1
Managed Switch with six 10/100 Mbps RJ45 ports and two FO ports in ST format for single mode	FL SWITCH 2206-2FX SM ST	2702333	1
Managed Switch with four 10/100 Mbps RJ45 ports, two SFX combo ports, and two SFX ports	FL SWITCH 2204-2TC-2SFX	2702334	1
Managed Switch with six 10/100 Mbps RJ45 ports and two SFX ports	FL SWITCH 2206-2SFX	2702969	1
Managed Switch with eight 10/100/1000 Mbps RJ45 ports	FL SWITCH 2308	2702652	1
Managed Switch with six 10/100/1000 Mbps RJ45 ports and two SFP ports	FL SWITCH 2306-2SFP	2702970	1
Managed Switch with four 10/100/1000 Mbps RJ45 ports, two Gigabit combo ports, and two SFP ports	FL SWITCH 2304-2GC-2SFP	2702653	1

Accessories

Description	Order designation	Order No.	Pcs./Pkt.
Program and configuration memory, plug-in, 2 Gbytes	SD FLASH 2GB	2988162	1
Program and configuration memory, plug-in, with MRP master license (MRM), 2 Gbytes	FL SD FLASH/MRM	2700270	1
FL Network Manager, SNMP-based configuration and firmware update software, for easy startup of Managed Switches	FL NETWORK MANAGER BASIC	2702889	1
Universal end bracket	E/NS 35 N	0800886	1
Gigabit SFP module for transmission up to 30 km with a wavelength of 1310 nm	FL SFP LX	2891767	1
Gigabit SFP module for transmission up to 1 km with a wavelength of 850 nm	FL SFP SX	2891754	1
Gigabit SFP module for transmission up to 80 km with a wavelength of 1550 nm	FL SFP LX LH	2989912	1
Gigabit SFP module for transmission up to 100 m	FL SFP GT	2989420	1
Gigabit SFP module for transmission up to 2 km with a wavelength of 1310 nm	FL SFP SX2	2702397	1
The narrow form-factor plug-in module provides a fiber optic interface with a data transmission speed of 100 Mbps with a wavelength of 1310 nm (long)	FL SFP FX	2891081	1
The narrow form-factor plug-in module provides a fiber optic interface with a data transmission speed of 100 Mbps with a wavelength of 1310 nm (long).	FL SFP FX SM	2891082	1
Fast Ethernet SFP WDM module for transmission up to a maximum of 20 km on a single fiber with a wavelength of 1310/1550 nm	FL SFP FE WDM20-A	2702437	1

FL SWITCH 2000

Description (Fortsetzung)	Order designation	Order No.	Pcs./Pkt.
Fast Ethernet SFP WDM module for transmission up to a maximum of 20 km on a single fiber with a wavelength of 1550/1310 nm.	FL SFP FE WDM20-B	2702438	1
Fast Ethernet SFP WDM set for transmission up to a maximum of 20 km on a single fiber with a wavelength of 1310/1550 nm	FL SFP FE WDM20-SET	2702439	1
Gigabit SFP WDM module for transmission up to a maximum of 10 km on a single fiber with a wavelength of 1310/1550 nm	FL SFP WDM10-A	2702440	1
Gigabit SFP WDM module for transmission up to a maximum of 10 km on a single fiber with a wavelength of 1310/1550 nm	FL SFP WDM10-B	2702441	1
Gigabit SFP WDM set for transmission up to a maximum of 10 km on a single fiber with a wavelength of 1310/1550 nm	FL SFP WDM10-SET	2702442	1
The FL DIN RA is installed in a standard, 19-inch rack (EIA-310-D, IEC 60297-3-100) to allow DIN rail mounted equipment to be rack mounted	FL DIN RA	2891053	1
Network monitoring with HMI/SCADA systems	FL SNMP OPC SERVER V3	2701139	1
PCB connector, plug, nominal current: 8 A, rated voltage (III/2): 160 V, number of positions: 5, pitch: 3.81 mm, connection method: screw connection with tension sleeve, color: gray, contact surface: tin	MCVW 1.5/ 5-ST-3.81 GY BD-GND	1715127	
PCB connector, plug, nominal current: 8 A, rated voltage (III/2): 160 V, number of positions: 5, pitch: 3.81 mm, connection method: screw connection with tension sleeve, color: gray, contact surface: tin	MCVW 1.5/ 5-ST-3.81 GY BD-D0	1715126	
PCB connector, plug, nominal current: 8 A, rated voltage (III/2): 160 V, number of positions: 5, pitch: 3.81 mm, connection method: Push-in spring connection, color: gray, contact surface: tin	FK-MCP 1,5/ 5-ST-3,81 GY	1884005	
PCB connector, plug, nominal current: 8 A, rated voltage (III/2): 160 V, number of positions: 5, pitch: 3.81 mm, connection method: Push-in spring connection, color: green, contact surface: tin	FMC 1,5/ 5-ST-3,81	1745920	
SNMP-based software in English, for detection and display of Ethernet networks with a maximum of 64 network nodes	FL VIEW 64	2701472	1
SNMP-based software in English, for detection and display of Ethernet networks with a maximum of 256 network nodes	FL VIEW 256	2701473	1
SNMP-based software in English, for detection and display of Ethernet networks with a maximum of 512 network nodes	FL VIEW 512	2701474	1
Fuse terminal block for cartridge fuse-link, cross section: 0.5 - 16 mm ² , AWG: 24 - 6, width: 12 mm, color: black	UK 10-DREHSILED 24 (5X20)	3005138	50
Lever-type fuse terminal block, black, for 5 x 20 mm cartridge fuse-links, with LED for 24 V DC	UT 4-HESILED 24 (5X20)	3046090	50
Thermomagnetic circuit breaker, 1-pos., for DIN rail mounting, 2 A	UT 6-TMC M 2A	0916605	6
Pre-assembled relay module with Push-in connection, consisting of: relay base with ejector and power contact relay. Contact type: 1 changeover contact. Input voltage: 24 V DC	RIF-0-RPT-24DC/21	2903370	1
FO patch cable, multimode, preconfigured, 1.0 m long, LC-LC connector	FL MM PATCH 1,0 LC-LC	2989158	1
FO patch cable, single mode, preconfigured, 1.0 m long, LC-LC connector	FL SM PATCH 1,0 LC-LC	2989187	1
FO patch cable, multimode, preconfigured, 1.0 m long, LC-SC connector	FL MM PATCH 1,0 LC-SC	2989161	1
FO patch cable, multimode, preconfigured, 1.0 m long, SC-SC connector	FL MM PATCH 1,0 SC-SC	2901805	1
FO patch cable, multimode, preconfigured, 1.0 m long, SC-ST connector	FL MM PATCH 1,0 SC-ST	2901809	1
FO patch cable, single mode, preconfigured, 1.0 m long, LC-SC connector	FL SM PATCH 1,0 LC-SC	2989190	1
FO patch cable, single mode, preconfigured, 1.0 m long, SC-SC connector	FL SM PATCH 1,0 SC-SC	2901829	1
FO patch cable, single mode, preconfigured, 1.0 m long, SC-ST connector	FL SM PATCH 1,0 SC-ST	2901832	1
Patch cable, CAT6, pre-assembled, 1.0 m long	FL CAT6 PATCH 1,0	2891385	10
Patch cable, CAT5, pre-assembled, 1.0 m long	FL CAT5 PATCH 1,0	2832276	10

HOTLINE:

If there are any problems that cannot be solved using this documentation, please call our hotline:



+ 49 5281 9-462888

A Appendix for document lists

A 1 List of figures

Section 1

Figure 1-1:	Dimensions of the FL SWITCH 2000	8
Figure 1-2:	Elements of the devices	9

Section 2

Figure 2-1:	Snapping the device onto the DIN rail	11
Figure 2-2:	Removing the device	12
Figure 2-3:	Operating the device with one power supply (example)	12
Figure 2-4:	Redundant operation with two power supplies (example)	13
Figure 2-5:	Connecting a relay to the digital alarm output	13
Figure 2-6:	Elements of the SFP modules	15
Figure 2-7:	Inserting the SFP modules (example)	15
Figure 2-8:	Position of the SD card slot	16

Section 3

Figure 3-1:	Settings for the BootP server	20
Figure 3-2:	BootP server	20
Figure 3-3:	FL Network Manager with BootP/DHCP reservation list displayed	21
Figure 3-4:	“IP Address Request Listener” window	22
Figure 3-5:	“Set IP Address” window with incorrect settings	23
Figure 3-6:	“Assign IP Address” window	23

Section 4

Section 5

Figure 5-1:	Login window	27
Figure 5-2:	Start page for web-based management (example)	28
Figure 5-3:	“Help & Documentation” web page	29
Figure 5-4:	“Device Status” web page	30
Figure 5-5:	“Technical Data” web page	30

Figure 5-6:	“Local Diagnostics” web page	31
Figure 5-7:	“Alarm & Events” web page	31
Figure 5-8:	“Port Table” web page	32
Figure 5-9:	“MAC Address Table” web page	32
Figure 5-10:	“System” web page	33
Figure 5-11:	“Firmware Update via HTTP” pop-up	34
Figure 5-12:	“Firmware Update via TFTP” pop-up	34
Figure 5-13:	“Advanced Configuration” pop-up	36
Figure 5-14:	“Advanced Configuration” pop-up	37
Figure 5-15:	“Security Context” pop-up	37
Figure 5-16:	“Administrator Password” configuration area	38
Figure 5-17:	“Quick Setup” web page	38
Figure 5-18:	“Network” web page	39
Figure 5-19:	ACD status information on the “Device Status” page	40
Figure 5-20:	“Service” web page	40
Figure 5-21:	“Port Configuration” web page	41
Figure 5-22:	“Port Configuration Table” web page	43
Figure 5-23:	“VLAN Configuration” web page	43
Figure 5-24:	“Multicast Filtering” web page	44
Figure 5-25:	“Spanning-Tree Configuration” configuration area	44
Figure 5-26:	“RSTP Port Configuration” web page	46
Figure 5-27:	“RSTP Port Configuration Table” web page	47
Figure 5-28:	“Security” web page	47
Figure 5-29:	“DHCP Service” web page	48
Figure 5-30:	“DHCP Port Local Service” pop-up	49
Figure 5-31:	“Local Events” web page	50
Figure 5-32:	“Quality of Service” web page	51
Figure 5-33:	“RSTP Diagnostic” web page	52
Figure 5-34:	“MRP Diagnostic” web page	53
Figure 5-35:	“Port Mirroring” web page	53
Figure 5-36:	“Trap Manager” web page	54
Figure 5-37:	“Port Counter” web page	55
Figure 5-38:	“Port Utilization” web page	55
Figure 5-39:	“SFP Diagnostics” web page	56

Section 6

Figure 6-1:	Configuration of a Telnet connection in PuTTY	57
-------------	---	----

Figure 6-2:	Command terminal in PuTTY	57
Figure 6-3:	Establishing a Telnet connection via Windows command prompt	58
Figure 6-4:	Command terminal in Windows command prompt	58

Section 7

Section 8

Figure 8-1:	“Link Layer Discovery Protocol” web page	66
Figure 8-2:	“LLDP Topology” web page	67

Section 9

Figure 9-1:	“Multicast Filtering” web page	69
Figure 9-2:	“Current Multicast Groups” web page	70

Section 10

Figure 10-1:	“VLAN Configuration” web page	71
Figure 10-2:	“Static VLAN Configuration” web page	72
Figure 10-3:	“VLAN Port configuration” web page	73
Figure 10-4:	“VLAN Port Configuration Table” web page	73
Figure 10-5:	“Current VLANs” web page	74

Section 11

Appendix A

B 2 List of tables

Section 1

Table 1-1:	9
------------	-------	---

Section 2

Table 2-1:	Pin assignment of RJ45 connectors	14
------------	---	----

Section 3

Table 3-1:	Operating modes in Smart mode	18
------------	-------------------------------------	----

Section 4

Section 5

Section 6

Table 6-1:	Structure of CLI commands	58
------------	---------------------------------	----

Table 6-2:	Structure of CLI commands	59
------------	---------------------------------	----

Section 7

Section 8

Table 8-1:	Event table for LLDP.....	66
------------	---------------------------	----

Section 9

Section 10

Section 11

Appendix A

C 3 Index

Numerics

24 V DC voltage	12
802.1w	45

A

ACD status	40
Address Conflict Detection.....	40
Address table	25, 75, 76, 78, 81
Admin Cost	47
Admin Edge	46
Admin Path Cost	46
Administrator password	38
Agent	64
Air pressure.....	75, 77, 79, 82
Alarm	31
Alarm contact	50
Ambient compatibility	75, 77, 79, 82
ASN1 SNMP objects.....	64
Auto Edge	46
Auto Query Ports.....	70
Automation Profile.....	38

B

BootP	19
BootP request	19
BPDU packets.....	26
Bridge Forward Delay	45
Bridge Hello Time	45
Bridge Max Age	45
Bridge Priority	45

C

Class of Service	26
Clear AQP.....	70
CoS.....	26
CRC error.....	25

D

Default IP address.....	18
Default Priority.....	42
Degree of protection	75, 77, 79, 82
Delivery state	17

Designated Bridge	46
Designated Cost	46
Designated Root	46
Destination address	25
Destination address field.....	25
Destination Port	54
Device status	30
DHCP Option 82	48
DHCP Relay Agent	48
DHCP server	18
DHCP Services	48
Diagnostics	10
DIN rail	11
dot1dBridge	63

E

Egress.....	54
etherMIB	63
Events.....	31
Extension BUQ	69
Extension FUQ.....	69

F

Factory settings.....	17
Fast Ring Detection	45
Firmware Update	33
FL Managed Infrastructure MIB	63
Forward Delay.....	45
Fragments.....	25
Functional earth grounding	14

G

Grounding	14
-----------------	----

H

Hello Time.....	45
Housing dimensions	75, 77, 78, 82
Humidity.....	75, 77, 79, 82

I

IEEE 802.1D	26
ifMIB.....	63
IGMP Query Version	69

IGMP Snooping..... 69
 Ingress 54
 IP configuration 17
 IP MIB 63
 IPAssign.exe 21

L

Learning addresses 25
 Link Monitoring..... 42
 List of Static VLANs 72
 LLDP 41
 lldpMIB..... 63
 Load distribution..... 13
 Local Events 50

M

MAC Address Table..... 32
 Management Information Base 63, 64
 Max Age..... 45
 MIB 63
 Mirroring..... 43, 54
 Monitored link 50
 Mounting 11
 Mounting position..... 75, 77, 79, 82
 Multi-address function..... 25
 Multicast/broadcast address 25

N

Network Redundancy..... 44

O

Operating Edge..... 46
 Operating modes 18
 Operating Path Cost..... 46
 Operating temperature 75, 77, 79, 82
 Option 82 48

P

Packet processing sequence 26
 Password 17, 38
 Path Cost 46
 pBridgeMIB..... 63
 Port Counter..... 55
 Port ID..... 46
 Port Mirroring 43, 54

Port Table 31
 Prioritization 26
 Priority..... 26
 Priority queues 26
 Processing queue 26
 Processing rules 26
 Protection class 75, 77, 79, 82

Q

qBridgeMIB..... 63
 QoS..... 26
 Quality of Service 26
 Query Interval 69
 Queue 26
 Quick Setup 38

R

Receive queue 26
 Redundancy 44
 Redundant operation 13
 Relay Agent 48
 Removal..... 11
 Reset 33
 RFC1213 MIB 63
 Ripple 75, 77, 79, 82
 RJ45 Ethernet connector 14
 rmon..... 63
 Root 46
 Root Cost..... 52
 Root Port..... 52
 RSTP 44
 rstpMIB 63

S

SFP modules 15
 SFP slot 14
 Simple Network Management..... 57, 63
 Smart mode 17
 SNMP 63
 SNMP interface..... 63
 snmpFrameworkMIB..... 63
 snmpMIB 63
 Snoop Aging Time 69
 Source and destination addresses..... 25
 Static Query Ports 70

Storage temperature	75, 77, 79, 82
Store and forward mode.....	25
Switch principle	75, 76, 78, 81

T

Tagged.....	71
Topology Change.....	52
Traffic classes	26
Transparent.....	71
Trap	63
Trap Manager	54
Tree structure of the MIB.....	64

U

User name	17
Utilization	55

V

VLAN/priority tag.....	26
------------------------	----

