




Current Sense Resistors R1, R2, R3  
 - 350mA => 0.3 Ohms

Use formula:  $I_{led} = V_{thd} / R_{set}$   
 $V_{thd} = 0.1$



open hardware

Released under the Creative Commons Attribution Share-Alike 3.0 License <a href="http://creativecommons.org/licenses/by-sa/3.0">http://creativecommons.org/licenses/by-sa/3.0</a>	⊗ ⊗
TITLE: picoBuck	SFE
Design by: Ethan Zonca/Mike Hord	REV: 10
Date: 6/27/2013 12:18:24 PM	Sheet: 1/1