

# DataMate Pro activation guide

MAC810/MAC820

The screenshot shows the DataMate Pro application window. The menu bar includes File, Connection, Route Manager, Set-up, To Meter, From Meter, Language, App Look, and Help. The left sidebar shows a 'Machine Manager' with four items: test motor, AHU plastics #1, AHU plastics #2, and NoMPMachine. The main area displays the 'DataMate' logo and an 'Activation' dialog box. The dialog box has a title bar with 'Activation' and 'Product Key' and a key icon. It contains the text 'Enter your product key to activate this product' and a five-part input field for the product key. Below this are two radio buttons: 'Activate Online (Recommended)' and 'Activate Offline'. A 'Paste Key' button is to the right of the product key input. A text box explains that for offline activation, the user must email their Product Key and Hardware Key to info@wilcoxon.com to receive an Unlock Key. The Hardware Key field is pre-filled with 'BA83B4E399'. The Unlock Key field is empty. At the bottom are 'Activate' and 'Cancel' buttons. A red banner at the bottom of the window reads 'Complete condition monitoring'. Four green callout boxes provide instructions: 1. Select ACTIVATE from the HELP menu. 2. Select ACTIVATE OFFLINE. 3. Email the PRODUCT KEY (sent with MAC unit) and HARDWARE KEY to info@wilcoxon.com. 4. Enter the UNLOCK KEY provided by Wilcoxon Sensing Technologies to activate DataMate Pro.

1. Select ACTIVATE from the HELP menu.

2. Select ACTIVATE OFFLINE.

3. Email the PRODUCT KEY (sent with MAC unit) and HARDWARE KEY to info@wilcoxon.com.

4. Enter the UNLOCK KEY provided by Wilcoxon Sensing Technologies to activate DataMate Pro.

Complete condition monitoring