

Change Notice

S, SW & SB Series

Changes in Production for S Toggles, SW Rockers & SB Pushbuttons

Type of Change:

- Engineering Part Number
- Product Appearance

1. S Toggle, SW Rocker and SB Pushbutton switches will have an update to the method of display for part numbers on the switch bodies. Previously, the part numbers were displayed on identification plates, which will be changed to laser application. The revision applies to standard, custom and UL/CSA approved products. See page 2 for tables of the effected part numbers.



Changes for S Toggles, SW Rockers, SB Pushbuttons

Method	Part Number	
	Before Change	After Change
Method	Displayed on Identification Plate	Displayed by Laser Marking
Color of Part No.	Black	Off-White

Notes

There are no changes to the switches' dimensions or specifications. The location of the part number may vary depending on the product. Contact the factory if more details are needed.

Type of Change:

- Engineering Part Number
- Product Appearance

2. S Toggles, SW Rockers and SB Pushbuttons will have a revision to the location of lot numbers on the switch cases. The lot numbers will change from placement on the front of the switches to the side, as depicted below. This will apply to standard, custom and UL/CSA approved products. Effected part numbers are shown on page 2.

Example: S6A	Lot Number	
	Before Change	After Change
Location of Lot Number on Switch Case		

Notes

There are no changes to the switches' dimensions or specifications. Contact the factory if more details are needed.

Effective Date

Production changes for S Toggles, SW Rockers and SB Pushbuttons will be effective November 2018.



NIKK SWITCHES

www.nkkswitches.com • 1.877.2BUYNKK (228.9655)

7850 East Gelding Drive • Scottsdale, AZ 85260 • Telephone 480.991.0942 • Fax 480.998.1435

Change Notice

S, SW & SB Series

Changes in Production for S Toggles, SW Rockers & SB Pushbuttons

S Toggles Part Numbers for Changes 1 & 2					
S1A	S1A/U	S1A/UC	S1AL	S1AW	S1AWF
S1F	S21A	S21AL	S21AW	S21AWF	S21F
S25AW	S25AWF	S28AW	S28AWF	S29AW	S29AWF
S2A	S2A/U	S2AL	S2AW	S2AWF	S2F
S331	S331/C	S331F	S331F/CUL	S331F/C-UL	S331F/U
S331R	S331T	S331T/U	S332	S332/U	S332F
S332F/U	S332R	S332T	S333	S333/CUL	S333/U
S333F	S333F/U	S333R	S333T	S333T/CUL	S335
S335/U	S335F	S335T	S338	S338/U	S338R
S338F	S338F/U	S338T	S338T/U	S339	S339R
S339T	S3A	S3A/U	S3AL	S3AW	S3AWF
S3F	S421	S421T	S422	S422T	S423
S423T	S425	S425T	S428	S428T	S429
S429T	S5AW	S5AWF	S6A	S6A/U	S6AL
S6AW	S6AWF	S6F	S7A	S7AL	S7ALF
S7AW	S7AWF	S7F	S8AW	S8AWF	S9AW
S9AWF	—	—	—	—	—

SW Rockers Part Numbers for Changes 1 & 2					
SW3001A	SW3002A	SW3003A	SW3006A	SW3006A/C	SW3006A/U
SW3006A/UCV	SW3007A	SW3008A	—	—	—

SB Pushbuttons Part Numbers for Changes 1 & 2					
SB221NC	SB221NO	SB221TNO	SB265/U	SB61A/U	SB63A
SB221NC/C	SB221NO-DC	SB265	SB61A	SB61B	SB63A/AT414C
SB221NC/U	SB221TNC	SB265/C	SB61A/AT414C	SB61B/AT414C	—



www.nkkswitches.com • 1.877.2BUYNKK (228.9655)

7850 East Gelding Drive • Scottsdale, AZ 85260 • Telephone 480.991.0942 • Fax 480.998.1435